

ENGINE

01

SECTION

01

MECHANICAL [WL-3]	01-10A
MECHANICAL	
[WL-C, WE-C]	01-10B
TECHNICAL DATA [WL-3] ...	01-50A

TECHNICAL DATA	
[WL-C, WE-C]	01-50B
SERVICE TOOLS [WL-3]	01-60A
SERVICE TOOLS	
[WL-C, WE-C]	01-60B

01-10A MECHANICAL [WL-3]

ENGINE MOUNTING [WL-3]	01-10A-2	CRANKSHAFT INSPECTION [WL-3] ...	01-10A-25
ENGINE DISMOUNTING [WL-3]	01-10A-3	CRANKSHAFT OIL CLEARANCE	
TIMING BELT DISASSEMBLY [WL-3] ..	01-10A-4	INSPECTION/REPAIR [WL-3]	01-10A-26
CYLINDER HEAD		CRANKSHAFT END PLAY	
DISASSEMBLY(I) [WL-3]	01-10A-6	INSPECTION/REPAIR [WL-3]	01-10A-26
CYLINDER HEAD DISASSEMBLY (II)		CONNECTING ROD INSPECTION	
[WL-3]	01-10A-8	[WL-3]	01-10A-26
CYLINDER BLOCK DISASSEMBLY (I)		CONNECTING ROD OIL CLEARANCE	
[WL-3]	01-10A-9	INSPECTION/REPAIR [WL-3]	01-10A-27
CYLINDER BLOCK DISASSEMBLY (II)		CONNECTING ROD SIDE CLEARANCE	
[WL-3]	01-10A-10	INSPECTION [WL-3]	01-10A-27
CYLINDER BLOCK DISASSEMBLY (III)		PISTON AND CONNECTING ROD	
[WL-3]	01-10A-15	INSPECTION [WL-3]	01-10A-28
CYLINDER HEAD INSPECTION/REPAIR		BOLT INSPECTION [WL-3]	01-10A-28
[WL-3]	01-10A-16	TENSIONER SPRING INSPECTION	
VALVE INSPECTION [WL-3]	01-10A-17	[WL-3]	01-10A-28
VALVE GUIDE INSPECTION [WL-3] ...	01-10A-18	VALVE CLEARANCE INSPECTION	
VALVE GUIDE REPLACEMENT [WL-3].	01-10A-19	[WL-3]	01-10A-29
VALVE SEAT		VALVE CLEARANCE ADJUSTMENT	
INSPECTION/REPAIR [WL-3]	01-10A-19	[WL-3]	01-10A-29
VALVE SPRING INSPECTION [WL-3] ..	01-10A-20	INJECTION TIMING ADJUSTMENT	
CAMSHAFT INSPECTION [WL-3]	01-10A-21	[WL-3]	01-10A-30
CAMSHAFT OIL CLEARANCE		GEAR CLEARANCE INSPECTION	
INSPECTION [WL-3]	01-10A-21	[WL-3]	01-10A-32
CAMSHAFT END PLAY		PLUNGER SPRING INSPECTION	
INSPECTION [WL-3]	01-10A-22	[WL-3]	01-10A-32
CYLINDER BLOCK		CYLINDER BLOCK ASSEMBLY (I)	
INSPECTION/REPAIR [WL-3]	01-10A-22	[WL-3]	01-10A-33
OIL JET VALVE, NOZZLE		CYLINDER BLOCK ASSEMBLY (II)	
INSPECTION [WL-3]	01-10A-23	[WL-3]	01-10A-36
PISTON INSPECTION [WL-3]	01-10A-23	CYLINDER BLOCK ASSEMBLY (III)	
PISTON CLEARANCE		[WL-3]	01-10A-42
INSPECTION/REPAIR [WL-3]	01-10A-23	CYLINDER HEAD ASSEMBLY (I)	
PISTON RING CLEARANCE		[WL-3]	01-10A-44
INSPECTION [WL-3]	01-10A-23	CYLINDER HEAD ASSEMBLY (II)	
PISTON PIN CLEARANCE		[WL-3]	01-10A-46
INSPECTION [WL-3]	01-10A-24	TIMING BELT ASSEMBLY [WL-3]	01-10A-51

MECHANICAL [WL-3]

ENGINE MOUNTING [WL-3]

1. Install the engine hanger (JE48 10 561C) or **SST** (303-050 (49 UN30 3050)) to the cylinder head using the bolt (99794 0820 or **M8X1.25, 6T**, length **20mm {0.79 in}**) as shown in the figure.





Tightening torque

18.6—25.5 N·m {1.90—2.60 kgf·m, 13.8—18.8 ft·lbf}

2. If the **SST** (303-050 (49 UN30 3050)) is used, use the **SST** (49 L017 5A0) when suspending the engine.

3. Install the **SST** (arms) to the holes as shown in the figure, and hand tighten the **SST** (bolts).

4. Assemble the **SSTs** (bolts, nuts and plate) to the specified positions.



MECHANICAL [WL-3]

5. Adjust the **SST** (bolts) so that 20 mm {0.79 in} or more of thread is exposed.
6. Align the **SSTs** (plate and arms) so that they are parallel by adjusting the **SSTs** (bolts and nuts).
7. Tighten the **SSTs** (bolts and nuts) to affix the **SST** firmly.
8. Mount the engine on the **SST** (engine stand).


Warning

- The self-locking brake system for the engine stand may not operate if the engine is held in an unbalanced position. This could lead to sudden, rapid movement of the engine and mounting stand handle and cause serious injury. Never hold the engine in an unbalanced position, and always grasp the rotating handle firmly when turning the engine.


9. Remove the engine hanger (JE48 10 561C) or **SST** (303-050 (49 UN30 3050)).
10. Drain the engine oil into a container.
11. Install the drain plug using new washer.

Tightening torque

29.4—41.2 N·m {3.00—4.20 kgf·m, 21.7—30.3 ft·lbf}



DBG110AEB105



DBG110AEB004

DCF011002000W02

ENGINE DISMOUNTING [WL-3]


1. Dismount in the reverse order of mounting.

MECHANICAL [WL-3]

TIMING BELT DISASSEMBLY [WL-3]

DCF011002000W03

1. Disassemble in the order shown in the figure.




DBG110AEBR05

1	Water pump
2	Vacuum pump
3	Cylinder head cover
4	Timing belt cover
5	Pulley plate

6	Tensioner, tensioner spring (See 01-10A-5 Tensioner, Tensioner Spring Disassembly Note.)
7	Timing belt (See 01-10A-5 Timing Belt Disassembly Note.)

Tensioner, Tensioner Spring Disassembly Note

1. Turn the crankshaft clockwise and align the timing marks as shown in the figure.




DBG110AEBR11

Timing Belt Disassembly Note

1. Mark the timing belt rotation on the belt for proper reinstallation.

Caution

- The following will damage the timing belt and shorten its life; forcefully twisting it, turning it inside out, or getting oil or grease on it.
- After removing the timing belt, do not move the crankshaft and/or camshaft pulley from this position because it can cause the valve and piston to contact and damage them.




DBG110AEBR10

MECHANICAL [WL-3]

CYLINDER HEAD DISASSEMBLY(I) [WL-3]

DCF011002000W04

1. Disassemble in the order shown in the figure.



DBG110AEBR08

1	Camshaft pulley (See 01-10A-7 Camshaft Pulley Disassembly Note.)
2	Seal plate
3	Camshaft cap (See 01-10A-7 Camshaft Cap Disassembly Note.)
4	Camshaft (See 01-10A-7 Camshaft Disassembly Note.)


5	Rocker arm
6	Water temperature sender unit
7	ECT sensor
8	Water outlet pipe
9	Blind cover
10	Cylinder head (See 01-10A-7 Cylinder Head Disassembly Note.)
11	Cylinder head gasket

Camshaft Pulley Disassembly Note

Caution

- Do not move the camshaft from this position because it can cause the valve and piston to contact each other and damage them.

- Hold the camshaft by using a wrench on the cast hexagon.



DBG110AEB015

Camshaft Cap Disassembly Note


Caution

- Removing the camshaft cap under load can break the camshaft. When removing the camshaft cap, loosen the locknut and the adjust screw to prevent the camshaft from pressing down the rocker arm.

Note

- Mark the camshaft cap so that they can be reinstalled in the position from which they were removed.

- Loosen the camshaft cap bolts in three or four steps in the order shown in the figure.




DBG110AEB025

Camshaft Disassembly Note

- Before removing the camshaft, inspect the camshaft oil clearance. (See 01-10A-21 CAMSHAFT OIL CLEARANCE INSPECTION [WL-3].)

Cylinder Head Disassembly Note

- Remove bolts A.
- Loosen the cylinder head bolts in two or three steps in the order shown in the figure.




DBG110AEB016

MECHANICAL [WL-3]

CYLINDER HEAD DISASSEMBLY (II) [WL-3]

DCF011002000W05

1. Disassemble in the order shown in the figure.




DBG110AEBR24

1	Pivot
2	Valve keeper (See 01-10A-8 Valve Keeper Disassembly Note.)
3	Upper valve spring seat
4	Valve spring

5	Lower valve spring seat
6	Valve
7	Valve seal (See 01-10A-9 Valve Seal Disassembly Note.)

Valve Keeper Disassembly Note

1. Remove the valve keeper using the SST.




DBG110AEB026

MECHANICAL [WL-3]

Valve Seal Disassembly Note

1. Remove the valve seal using the SST.




DBG110AEB104

CYLINDER BLOCK DISASSEMBLY (I) [WL-3]

1. Disassemble in the order shown in the figure.

DCF011002000W06



DBG110AEB033


1	Oil drain plug
2	Oil pan (See 01-10A-10 Oil Pan Disassembly Note.)

3	Oil strainer
4	Oil pipe

MECHANICAL [WL-3]

Oil Pan Disassembly Note

1. Remove the oil pan using a separator tool.




DBG110AEB035

CYLINDER BLOCK DISASSEMBLY (II) [WL-3]

1. Disassemble in the order shown in the figure.

DCF011002000W07



DBG110AEBR40

1	Crankshaft pulley (See 01-10A-11 Crankshaft Pulley Disassembly Note.)
2	Fuel injection pump pulley (See 01-10A-11 Fuel Injection Pump Pulley Disassembly Note.)
3	Timing gear cover (See 01-10A-12 Timing Gear Cover Disassembly Note.)

4	Oil pump
5	Fuel injection pump gear (See 01-10A-12 Fuel Injection Pump Gear Disassembly Note.)
6	Timing gear
7	Fuel injection pump

MECHANICAL [WL-3]

8	Timing gear case (See 01-10A-14 Timing Gear Case Disassembly Note.)
9	Flywheel (See 01-10A-14 Flywheel Disassembly Note.)
10	End plate
11	Rear cover (See 01-10A-14 Rear Cover Disassembly Note.)

12	Oil pump cover
13	Driven gear
14	Plug
15	Plunger spring
16	Control plunger
17	Oil pump body


01

Crankshaft Pulley Disassembly Note


1. Remove the crankshaft pulley using the SST.

Caution

- The CKP sensor plate is a very important part for engine operation control; any deformation of the plate may disable the operation control.
When disassembling/assembling the crankshaft pulley, be very careful not to deform the plate by interference with other parts or improper handling.




DBG110AEB042



DBG110AWB021

Fuel Injection Pump Pulley Disassembly Note

1. Remove the fuel injection pump pulley using the SST.




DBG110AEB043

MECHANICAL [WL-3]


Timing Gear Cover Disassembly Note

1. Remove the timing gear cover using a separator tool.



DBG110AEB044


2. Remove the oil seal using a screwdriver protected with a rag.



DBG110AEB045

Fuel Injection Pump Gear Disassembly Note

1. Set the No.1 cylinder to TDC of compression.
2. Rotate the flywheel ring gear from TDC to approximately 30° BTDC (about 13 teeth on the gear).




DBG110AEB046

3. Verify that the end-gap (V groove) of the timing gear case and the chip cut gear of the fuel injection pump gear are aligned.

Note

- If the chip cut gear is hard to find, move the fuel injection pump gear on notch back and forth, then check the chip cut gear.



DBG110AEBR8

MECHANICAL [WL-3]

4. Fix the scissors gear to the fuel injection pump gear using a lock bolt (M8×1.25; length under the bolt head is approximately 14 mm {0.55 in}).

Warning


- When removing the fuel injection pump gear, be sure to secure the scissors gear to the fuel injection pump gear using a lock bolt (M8×1.25; length under the bolt head is approximately 14 mm {0.55 in}). Otherwise, the scissors gear will rotate with the spring force, causing personal injury.

Caution

- When removing the fuel injection pump gear, be sure to secure the scissors gear to the fuel injection pump gear using a lock bolt (M8×1.25; length under the bolt head is approximately 14 mm {0.55 in}) to prevent the scissors gear from rotating with the spring force. Otherwise, the scissors gear will not align with the fuel injection pump gear, and the fuel injection pump gear with the scissors gear will not engage with the idler gear.


Note

- The fuel injection pump gear with a scissors gear has a lock bolt hole.



DBG110AEBR97


5. Hold the crankshaft using the SST and loosen the gear nut.



DBG110AEB047

MECHANICAL [WL-3]


6. Remove the fuel injection pump gear using the **SST**.



DBG110AEBR48

Timing Gear Case Disassembly Note


1. Remove the timing gear case using the separator tool.



DBG110AEB050

Flywheel Disassembly Note


1. Remove the flywheel using the **SST**.



DBG110AEBR56

Rear Cover Disassembly Note

1. Remove the oil seal using a screwdriver protected with a rag.




DBG110AEB052

MECHANICAL [WL-3]

CYLINDER BLOCK DISASSEMBLY (III) [WL-3]

DCF011002000W08

1. Disassemble in the order shown in the figure.



DBG110AEBR67

1	Connecting rod cap (See 01-10A-15 Connecting Rod Cap Disassembly Note.)
2	Lower connecting rod bearing
3	Piston, connecting rod (See 01-10A-15 Piston, Connecting Rod Disassembly Note.)
4	Upper connecting rod bearing
5	Piston ring
6	Piston pin clip
7	Piston pin (See 01-10A-16 Piston Pin Disassembly Note.)

8	Piston
9	Connecting rod
10	Main bearing cap (See 01-10A-16 Main Bearing Cap Disassembly Note.)
11	Lower main bearing, lower thrust bearing
12	Crankshaft (See 01-10A-16 Crankshaft Disassembly Note.)
13	Upper main bearing, upper thrust bearing
14	Oil jet valve, nozzle
15	cylinder block

Connecting Rod Cap Disassembly Note

- Before removing the connecting rod cap, inspect the connecting rod side clearance. (See 01-10A-27 CONNECTING ROD SIDE CLEARANCE INSPECTION [WL-3].)


Piston, Connecting Rod Disassembly Note

- Before removing the piston and connecting rod, inspect the connecting rod oil clearance. (See 01-10A-27 CONNECTING ROD OIL CLEARANCE INSPECTION/REPAIR [WL-3].)
- Inspect the oscillation torque. (See 01-10A-28 PISTON AND CONNECTING ROD INSPECTION [WL-3].)

MECHANICAL [WL-3]

Piston Pin Disassembly Note


1. Remove the piston pin using the SST.



DBG110AEB069

Main Bearing Cap Disassembly Note

1. Before removing the main bearing cap, inspect the crankshaft end play. (See 01-10A-26 CRANKSHAFT END PLAY INSPECTION/REPAIR [WL-3].)
2. Loosen the main bearing cap bolts in two or three steps in the order shown in the figure.



DBG110AEB070

Crankshaft Disassembly Note

1. Before removing the crankshaft, inspect the main journal oil clearance. (See 01-10A-26 CRANKSHAFT OIL CLEARANCE INSPECTION/REPAIR [WL-3].)


CYLINDER HEAD INSPECTION/REPAIR [WL-3]

1. Inspect the cylinder head surface for cracks. Replace the cylinder head if necessary.
2. Inspect for the following and repair or replace.
 - (1) Sunken valve seats
 - (2) Excessive camshaft oil clearance and end play
3. Measure the cylinder head for distortion in the seven directions as shown in the figure.

Maximum cylinder head distortion

X distortion: 0.02 mm {0.0008 in}

Y distortion: 0.05 mm {0.0020 in}



DBG110AEB115


MECHANICAL [WL-3]

01

4. Measure the receded or projected amount of combustion chamber insert from the cylinder head surface.
 - If it exceeds the maximum specification, replace the cylinder head.

Maximum combustion chamber recession
0.02 mm {0.0008 in}


Maximum combustion chamber projection
0.005 mm {0.0002 in}



DBG110AEB074

5. Inspect the combustion chamber insert crack.
 - If it exceeds the limit specification, replace the cylinder head.

Combustion chamber crack
Limit: 10mm {0.39 in}




DBG110AEB075

6. Measure the manifold contact surface distortion as shown in the figure.
 - If the distortion exceeds the maximum specification, grind the surface or replace the cylinder head.

Maximum manifold contact surface distortion
0.05 mm {0.0020 in}

Maximum manifold contact surface grinding
0.15 mm {0.0059 in}



DBG110AEB076

VALVE INSPECTION [WL-3]


1. Measure the valve head margin thickness of each valve.
 - If it exceeds the standard specification, replace the valve.

Standard valve margin thickness
IN: 1.5 mm {0.059 in}
EX: 0.75 mm {0.030 in}

2. Measure the length of each valve. Replace the valve if necessary.
 - If it is less than the minimum specification, replace the valve.

Standard valve length
IN: 111.6—112.1 mm {4.394—4.413 in}
EX: 111.5—112.0 mm {4.390—4.409 in}

Minimum valve length
IN: 111.35 mm {4.384 in}
EX: 111.25 mm {4.380 in}



DCF011012111W01

B3E0110ER68

MECHANICAL [WL-3]

3. Measure the stem diameter of each valve in the X and Y directions at the three points (A, B, and C) shown in the figure.

- If it is less than the minimum specification, replace the valve.

Standard valve stem diameter


IN: 6.970—6.985 mm {0.2745—0.2749 in}

EX: 6.965—6.980 mm {0.2743—0.2748 in}

Minimum valve stem diameter

IN: 6.920 mm {0.2724 in}

EX: 6.915 mm {0.2722 in}



DBG110AEB106


VALVE GUIDE INSPECTION [WL-3]

1. Measure the inner diameter of each valve guide in the X and Y directions at the three points (A, B, and C) shown in the figure.

- If it is not within the specification, replace the valve guide.

Standard valve guide inner diameter

7.025—7.045 mm {0.2766—0.2773 in}



DCF011010280W01


DBG110AEB108

2. Measure the protrusion height (dimension A) of each valve guide without lower valve spring seat.

- If it is not within the specification, replace the valve guide.

Standard valve guide height

14.0—14.5 mm {0.552—0.570 in}



DBG110AEB077


MECHANICAL [WL-3]

DCF011010280W02

VALVE GUIDE REPLACEMENT [WL-3]

Valve Guide Removal

1. Remove the valve guide from the combustion chamber side using the **SST**.




DBG110AEB107

Valve Guide Installation

1. Assemble the **SSTs** so that depth L is as specified.

Depth L

14.0—14.5 mm {0.552—0.570 in}




DBG110AEB110

2. Tap the valve guide in from the side opposite the combustion chamber until the **SST** contacts the cylinder head.
3. Verify that the valve guide projection height is within the specification.

Standard valve guide height

14.0—14.5 mm {0.552—0.570 in}



B3E0110E072

VALVE SEAT INSPECTION/REPAIR [WL-3]


DCF011010102W01

1. Measure the seat contact width.
 - If it is not within the specification, resurface the valve seat using the **45°** valve seat cutter.

Standard valve seat contact width

IN: 1.6—2.2 mm {0.063—0.086 in}

EX: 1.7—2.3 mm {0.067—0.090 in}



DBG110AEB109

MECHANICAL [WL-3]

2. Verify that the valve seating position is at the center of the valve face.
 - If the seating position is too high, correct the valve seat using a 60° cutter, and then a 45° cutter.
 - If the seating position is too low, correct the valve seat using a 37° (IN) or 30° (EX) cutter, and a 45° cutter.

Valve seat angle

IN: 45°

EX: 45°

3. Measure the receded amount from the cylinder head surface.
 - If it exceeds the maximum specification, replace the cylinder head.

Standard valve recession


IN: 0.61—1.09 mm {0.025—0.042 in}

EX: 0.71—1.19 mm {0.028—0.046 in}


Maximum valve recession

IN: 1.50 mm {0.059 in}

EX: 1.60 mm {0.063 in}



DBG110AEBR75



DBG110AEB112

VALVE SPRING INSPECTION [WL-3]


1. Apply a pressing force to the pressure spring and check the spring height.
 - If it is not within the specification, replace the valve spring.

Valve spring installation pressing force

238—269 N {25—27 kgf, 54—60 lbf}

Valve spring installation height

35.5 mm {1.40 in}




DBG0110AEB11

2. Measure the amount the valve spring is out-of-square.
 - If it exceeds the maximum specification, replace the valve spring.

Maximum valve spring out-of-square

2.0° (1.70mm {0.067 in})



DBG110AEB079

MECHANICAL [WL-3]


CAMSHAFT INSPECTION [WL-3]

DCF011012420W01

01

1. Set the No.1 and No.5 journals on V-blocks. Measure the camshaft runout.
 - If it exceeds the maximum specification, replace the camshaft.

Maximum camshaft runout
0.03 mm {0.0012 in}




DBG110AEB114

2. Measure the cam lobe height at the two points as shown in the figure.
 - If it is less than the minimum specification, replace the camshaft.

Standard cam lobe height
IN: 42.400—42.500 mm {1.6692—1.6732 in}
EX: 42.395—42.495 mm {1.6691—1.6730 in}

Minimum cam lobe height
IN: 42.050 mm {1.6555 in}
EX: 42.045 mm {1.6711 in}




DBG110AEB080

3. Measure the journal diameters in the X and Y directions at the two points (A and B) as shown in the figure.
 - If it is less than the minimum specification, replace the camshaft.

Standard cam journal diameter
No.1, No.5: 25.940—25.965 mm {1.0213—1.0222 in}
No.2—No.4: 25.910—25.935 mm {1.0201—1.0210 in}

Minimum cam journal diameter
No.1, No.5: 25.890 mm {1.0193 in}
No.2—No.4: 25.860 mm {1.0181 in}



DBG110AEB081


CAMSHAFT OIL CLEARANCE INSPECTION [WL-3]

DCF011012420W02

1. Position a plastigage on top of the journals in the axial direction.
2. Install the camshaft cap. (See 01-10A-49 Camshaft Cap Assembly Note.)
3. Remove the camshaft cap. (See 01-10A-7 Camshaft Cap Disassembly Note.)
4. Measure the oil clearance.
 - If it exceeds the maximum specification, replace the camshaft.

Standard camshaft clearance
No.1, 5: 0.035—0.081 mm {0.0014—0.0031 in}
No.2—4: 0.065—0.111 mm {0.0026—0.0043 in}

Maximum camshaft clearance
No.1, 5: 0.12 mm {0.0047 in}
No.2—4: 0.15 mm {0.0059 in}



DBG110AEB082

MECHANICAL [WL-3]

CAMSHAFT END PLAY INSPECTION [WL-3]


DCF011012420W03

1. Install the camshaft cap. (See 01-10A-49 Camshaft Cap Assembly Note.)
2. Measure the camshaft end play.
 - If it exceeds the maximum specification, replace the cylinder head or camshaft.

Standard camshaft end play
0.030—0.160 mm {0.0012—0.0062 in}

Maximum camshaft end play
0.20 mm {0.0079 in}

3. Remove the camshaft cap. (See 01-10A-7 Camshaft Cap Disassembly Note.)




DBG110AEB083

CYLINDER BLOCK INSPECTION/REPAIR [WL-3]

DCF011010300W01

1. Measure the distortion of the cylinder block top surface in the seven directions as shown in the figure.
 - If the distortion exceeds the maximum specification, replace the cylinder head.

Maximum cylinder block distortion
X direction: 0.02 mm {0.0008 in}
Y direction: 0.05 mm {0.0020 in}




DBG110AEB115

2. Measure the cylinder bore using the cylinder gauge. Measurement positions are in the X and Y directions at 83 mm {3.27 in} below the top surface of the cylinder.
 - If the cylinder bore exceeds the wear limit, replace the cylinder block or rebore the cylinder and install the oversized pistons so that the specified piston-to-cylinder clearance is obtained.

Note

- Base the boring diameter on the diameter of an oversized piston. All cylinders must be the same diameter.



ADA2224ER91

Cylinder bore size

Standard: 93.000—93.022 mm {3.6615—3.6622 in}
0.25 {0.01} oversize: 93.250—93.272 mm {3.6713—3.6721 in}
0.50 {0.02} oversize: 93.500—93.522 mm {3.6811—3.6819 in}

Cylinder bore wear limit

0.15 mm {0.0059 in}

MECHANICAL [WL-3]


OIL JET VALVE, NOZZLE INSPECTION [WL-3]

1. Apply compressed air to oil jet valve A and verify that air passes through oil jet valve B.
 - If it is not within the specification, replace the oil jet.

Oil jet air pressure

137.6—196.4 kPa {1.5—2.0 kgf/cm², 20—28 psi}

2. Check the oil jet nozzle for clogs. Replace the nozzle if necessary.



DCF011010730W01

DBG110AEB085

PISTON INSPECTION [WL-3]


1. Measure the outer diameter of each piston at right angle (90°) to the piston pin, 17 mm {0.67 in} from the lower end of the piston.
 - If it is not within the specification, replace the piston.

Piston diameter

Standard: 92.951—92.977 mm {3.6595—3.6605 in}

0.25 {0.0098} oversize: 93.186—93.212 mm {3.6688—3.6697 in}

0.50 {0.02} oversize: 93.436—93.462 mm {3.6786—3.6795 in}



DCF011011010W01

DBG110AEBR74

PISTON CLEARANCE INSPECTION/REPAIR [WL-3]

1. Measure the piston-to-cylinder clearance.
 - If it exceeds the maximum specification, replace the piston or rebore the cylinders to fit the oversized piston.

Standard piston clearance

0.055—0.073 mm {0.0022—0.0028 in}

Maximum piston clearance

0.15 mm {0.0059 in}

2. If the piston is replaced, the piston rings must also be replaced.

PISTON RING CLEARANCE INSPECTION [WL-3]

1. Measure the piston ring-to-ring land clearance around the entire circumference.
 - If it exceeds the maximum specification, replace the piston and piston ring.

Standard piston ring clearance


Top: 0.06—0.10 mm {0.0024—0.0039 in}

Second: 0.04—0.08 mm {0.0016—0.0031 in}

Oil: 0.03—0.07 mm {0.0012—0.0027 in}

Maximum piston ring clearance

0.15 mm {0.0059 in}



DCF011011010W03

DBG110AEB116

2. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.

MECHANICAL [WL-3]

- Measure each piston ring end gap with a feeler gauge.
 - If it exceeds the maximum specification, replace the piston ring.

Standard piston ring end gap


Top: 0.22—0.32 mm {0.0087—0.0125 in}

Second: 0.32—0.47 mm {0.0126—0.0185 in}

Oil: 0.22—0.37 mm {0.0087—0.0145 in}

Maximum piston ring end gap

1.0 mm {0.039 in}




DBG110AEB087

PISTON PIN CLEARANCE INSPECTION [WL-3]

- Measure each piston pin bore diameter in the X and Y directions at the four points (A, B, C, and D) as shown in the figure.

Standard piston pin bore diameter

31.997—32.007 mm {1.2598—1.2601 in}




DCF011011010W04

DBG110AEB088

- Measure each connecting rod small end inner diameter in the X and Y directions as shown in the figure.

Standard connecting rod small end inner diameter

32.012—32.033 mm {1.2604—1.2611 in}



DBG110AEB117

- Measure each piston pin diameter in the X and Y directions at the four points (A, B, C and D) as shown in the figure.


Standard piston pin diameter

31.994—32.000 mm {1.25961—1.25984 in}

- Calculate the piston pin-to-piston pin bore clearance.
 - If it is not within the specification, replace the piston or the piston pin.

Standard piston pin-to-piston pin bore clearance

−0.003—0.013 mm {−0.00011—0.00051 in}



DBG110AEB118

- Calculate the connecting rod small end-to-piston pin clearance.
 - If it is not within the specification, replace the connecting rod or the piston pin.

Standard connecting rod small end-to-piston pin clearance


0.012—0.039 mm {0.00048—0.00153 in}

CRANKSHAFT INSPECTION [WL-3]

DCF011011301W01

1. Measure the crankshaft runout.
 - If it exceeds the maximum specification, replace the crankshaft.

Maximum crankshaft runout
0.05 mm {0.0020 in}



DBG110AEB089

2. Measure the main journal or crank pin diameter in the X and Y directions at the two points (A and B) as shown in the figure.

- If it is not within the specification or if it exceeds the maximum off-round, grind the main journal or crank pin with an undersized bearing.

Main journal diameter

Standard

No.1, 2, 4, 5: 66.937—66.955 mm {2.6354—2.6360 in}

No.3: 66.920—66.938 mm {2.6347—2.6353 in}

0.25 {0.01} undersize

No.1, 2, 4, 5: 66.687—66.705 mm {2.6255—2.6261 in}

No.3: 66.670—66.688 mm {2.6248—2.6255 in}

0.50 {0.02} undersize

No.1, 2, 4, 5: 66.437—66.455 mm {2.6157—2.6163 in}

No.3: 66.420—66.438 mm {2.6150—2.6156 in}

0.75 {0.03} undersize

No.1, 2, 4, 5: 66.187—66.205 mm {2.6058—2.6064 in}

No.3: 66.170—66.188 mm {2.6052—2.6058 in}

Main journal wear limit

0.05 mm {0.0020 in}

Main journal out-of-round

0.03 mm {0.0012 in}

Crank pin diameter

Standard: 54.940—54.955 mm {2.1630—2.1635 in}

0.25 {0.01} undersize: 54.690—54.705 mm {2.1532—2.1537 in}

0.50 {0.02} undersize: 54.440—54.455 mm {2.1434—2.1438 in}


0.75 {0.03} undersize: 54.190—54.205 mm {2.1335—2.134 in}

Crank pin wear limit

0.05 mm {0.0020 in}

Crank pin out-of-round

0.03 mm {0.0012 in}



DBG110AEB090

MECHANICAL [WL-3]

CRANKSHAFT OIL CLEARANCE INSPECTION/REPAIR [WL-3]

DCF011011301W02

1. Position a plastigage on top of the journals in the axial direction.
2. Install the main bearing cap. (See 01-10A-34 Main Bearing Cap Assembly Note.)
3. Remove the main bearing cap. (See 01-10A-16 Main Bearing Cap Disassembly Note.)
4. Measure the main journal oil clearance.
 - If the clearance exceeds the maximum specification, replace the main bearing or grind the main journal and install the undersize bearings so that the specified oil clearance is obtained.

Standard main journal clearance

No.1, 2, 4, 5: 0.027—0.046 mm {0.0011—0.0018 in}

No.3: 0.044—0.063 mm {0.0018—0.0025 in}

Maximum main journal clearance

0.08 mm {0.0031 in}

Main bearing thickness

Standard: 2.006—2.021 mm {0.0790—0.0795 in}

0.25 {0.01} undersize: 2.124—2.134 mm {0.0837—0.0840 in}


0.50 {0.02} undersize: 2.249—2.259 mm {0.0886—0.0889 in}

0.75 {0.03} undersize: 2.374—2.384 mm {0.0935—0.0938 in}

CRANKSHAFT END PLAY INSPECTION/REPAIR [WL-3]

DCF011011301W03

1. Install the main bearing cap. (See 01-10A-34 Main Bearing Cap Assembly Note.)
2. Measure the crankshaft end play.
 - If the end play exceeds the maximum specification, replace the thrust bearing or grind the crankshaft and install an oversized bearing so that the specified end play is obtained.



DBG110AEB120

Standard crankshaft end play

0.040—0.282 mm {0.0016—0.0111 in}

Maximum crankshaft end play

0.3 mm {0.012 in}

Thrust bearing thickness

Standard: 2.454—2.506 mm {0.0967—0.0986 in}

0.35 {0.014} oversize: 2.629—2.681 mm {0.1036—0.1055 in}

3. Remove the main bearing cap. (See 01-10A-16 Main Bearing Cap Disassembly Note.)

CONNECTING ROD INSPECTION [WL-3]

DCF011011211W01

1. Measure each connecting rod for bending and distortion.
 - If it exceeds the maximum specification, replace the connecting rod.

Maximum connecting rod bending


0.075 mm {0.0030 in} /50 mm {2.0 in}

Maximum connecting rod distortion

0.18 mm {0.0071 in} /50 mm {2.0 in}

Connecting rod center-to-center distance

151.96—152.04 mm {5.9827—5.9858 in}




DBG110AEB119

MECHANICAL [WL-3]

2. Measure the length of the connecting rod bolt.
 - If it exceeds the maximum specification, replace the connecting rod and connecting rod cap.

Standard connecting rod bolt length
67.5—68.5 mm {2.66—2.69 in}

Maximum connecting rod bolt length
69 mm {2.7 in}



DBG110AEB092

01
1

CONNECTING ROD OIL CLEARANCE INSPECTION/REPAIR [WL-3]

DCF011011211W02

1. Position a plastigage on top of the journals in the axial direction.
2. Install the connecting rod cap. (See 01-10A-35 Piston, Connecting Rod Assembly Note.)
3. Remove the connecting rod cap.
4. Measure the crankpin oil clearance.
 - If the clearance exceeds the maximum, replace the connecting rod bearing or grind the crankpin and use undersized bearings so that the specified clearance is obtained.

Standard connecting rod oil clearance
0.025—0.052 mm {0.0010—0.0020 in}

Maximum connecting rod oil clearance
0.08 mm {0.0031 in}


Connecting rod bearing thickness

Standard: 1.507—1.516 mm {0.0594—0.0596 in}

0.25 {0.01} **undersize:** 1.624—1.634 mm {0.0640—0.0643 in}

0.50 {0.02} **undersize:** 1.749—1.759 mm {0.0689—0.0692 in}

0.75 {0.03} **undersize:** 1.874—1.884 mm {0.0738—0.0741 in}



DBG110AEB121


CONNECTING ROD SIDE CLEARANCE INSPECTION [WL-3]

DCF011011211W03

1. Install the connecting rod cap. (See 01-10A-35 Piston, Connecting Rod Assembly Note.)
2. Measure the connecting rod large end side clearance.
 - If it exceeds the maximum specification, replace the connecting rod and connecting rod cap.

Standard connecting rod side clearance
0.110—0.262 mm {0.0044—0.0103 in}

Maximum connecting rod side clearance
0.35 mm {0.014 in}




DBG110AEB122

3. Remove the connecting rod cap.

MECHANICAL [WL-3]

PISTON AND CONNECTING ROD INSPECTION [WL-3]

1. Check the oscillation torque as shown in the figure. If the large end does not drop by its own weight, replace the piston or the piston pin.



DBG110AEB093

BOLT INSPECTION [WL-3]

1. Measure the length of each bolt.
 - If it exceeds the maximum specification, replace the bolt.

Cylinder head bolt length

Bolt head mark W


Standard length: 101.2—101.8 mm {3.985—4.007 in}

Maximum length: 102.5 mm {4.035 in}

Bolt head mark N

Standard length: 113.2—113.8 mm {4.457—4.480 in}

Maximum length: 114.5 mm {4.508 in}



DBG110AEB097

Main bearing cap bolt length

Standard length: 84.7—85.3 mm {3.34—3.35 in}


Maximum length: 86.0 mm {3.39 in}

TENSIONER SPRING INSPECTION [WL-3]

1. Measure the free length of the tensioner spring.
 - If it exceeds the standard specification, replace the tensioner spring.

Standard tensioner spring length

63.0 mm {2.48 in}




DBG110AEB098

MECHANICAL [WL-3]

VALVE CLEARANCE INSPECTION [WL-3]

1. Turn the crankshaft and align the timing mark so that the piston of the No.1 or No.4 cylinder is at TDC of compression.
2. Measure valve clearances A with the No.1 cylinder at TDC of compression, and those of B with the No.4 cylinder at TDC of compression.
 - If it is not within the specification, adjust and recheck the valve clearance.

DCF011012111W02




DBG110AEB099

Valve clearance (engine cold)

IN: 0.05—0.15 mm {0.0020—0.0059 in}

EX: 0.15—0.25 mm {0.0060—0.0098 in}

3. Turn the crankshaft one full turn and measure the remaining valve clearances. Adjust if necessary.




DBG110AEB100

VALVE CLEARANCE ADJUSTMENT [WL-3]

DCF011012111W03

Caution


- Loosening the locknut and the adjust screw while the cam lobe is not pressing down the rocker arm will damage the claw of the rocker arm. When loosening the locknut and the adjust screw, rotate the crankshaft clockwise and be sure that the cam lobe presses down the rocker arm firmly as shown in the figure.
1. Remove the cylinder head cover.
 2. Turn the crankshaft and align the timing mark so that the piston of the No. 1 or No. 4 cylinders is at TDC of the compression.



DBG110AWB002

MECHANICAL [WL-3]

- Adjust the valve clearances A with the No.1 cylinder at TDC of compression, and those of B with the No.4 cylinder at TDC of compression.



DBG110AWB001

Valve clearance

IN: 0.05 — 0.15 mm {0.0020 — 0.0059 in}

[Engine cold]

0.15 mm {0.0059 in}

[Engine hot (reference)]

EX: 0.15 — 0.25 mm {0.0060 — 0.0098 in}


[Engine cold]

0.25 mm {0.0098 in}

[Engine hot (reference)]

Tightening torque (locknut)

16—20 N·m {1.7—2.0 kgf·m, 12—14 ft·lbf}



DBG110AWB003

- Turn the crankshaft one full turn and adjust the remaining valve clearances.


INJECTION TIMING ADJUSTMENT [WL-3]

DCF011002000W09

Caution


- Excessive tension on the timing belt may cause damage to the timing belt and camshaft. If the bolt and nuts of the fuel injection pump are temporarily loosened, re-tension the timing belt.

- Loosen the bolts and nuts of the fuel injection pump and bracket.



DBG110AEBR76


- Rotate the crankshaft clockwise and align the crankshaft pulley TDC mark (yellow mark) with the indicator pin.
- Remove the hydraulic head plug of the fuel injection pump.




DBG110AEBR81

MECHANICAL [WL-3]

4. Insert the **SST** into the hydraulic head plug hole and install it so that the dial gauge indicates approx. **2 mm {0.08 in.}**.




5. Rotate the crankshaft counterclockwise and find the place where the dial gauge needle does not move near approx. **30° BTDC**. (**SST** installation bolt hole of crankshaft pulley and indicator pin align at approx. **30° BTDC**)
6. Set the dial gauge to **0 mm {0 in.}**.




7. Rotate the crankshaft clockwise and read the dial gauge when the **10° ATDC** mark (white mark) of the crankshaft pulley and the indicator pin align.
8. Adjust the dial gauge within the specification.

Fuel injection pump plunger adjustment value
0.95—1.05 mm {0.038—0.041 in.}



9. Tighten the fuel injection pump in the order shown in the figure.
10. Remove the **SST** and install the hydraulic head plug through a new gasket.
11. Re-tension the timing belt.



MECHANICAL [WL-3]


GEAR CLEARANCE INSPECTION [WL-3]

DCF011019220W01

1. Measure the following clearance.
 - If it exceeds the maximum specification, replace the gear and/or pump body.

Standard oil pump tip clearance
0.10—0.19 mm {0.0040—0.0074 in}


Maximum oil pump tip clearance
0.20 mm {0.0079 in}



DBG110AEB101

Standard oil pump side clearance
0.04—0.09 mm {0.0016—0.0035 in}

Maximum oil pump side clearance
0.15 mm {0.0059 in}




DBG110AEB102

PLUNGER SPRING INSPECTION [WL-3]

DCF011014116W01

1. Measure the free length of plunger spring.
 - If it exceeds the standard specification, replace the plunger spring.

Standard plunger spring length
43.8 mm {1.72 in}




DBG110AEB103

MECHANICAL [WL-3]

CYLINDER BLOCK ASSEMBLY (I) [WL-3]

DCF011002000W10

1. Assemble in the order indicated in the table.



DBG110AEBR68

1	Cylinder block
2	Oil jet valve, nozzle
3	Upper main bearing, upper thrust bearing
4	Crankshaft
5	Lower main bearing, lower thrust bearing
6	Main bearing cap (See 01-10A-34 Main Bearing Cap Assembly Note.)
7	Connecting rod (See 01-10A-34 Piston, Connecting Rod, Piston Pin Assembly Note.)
8	Piston (See 01-10A-34 Piston, Connecting Rod, Piston Pin Assembly Note.)

9	Piston pin (See 01-10A-34 Piston, Connecting Rod, Piston Pin Assembly Note.)
10	Piston pin clip
11	Piston ring (See 01-10A-35 Piston Ring Assembly Note.)
12	Upper connecting rod bearing
13	Piston, connecting rod (See 01-10A-35 Piston, Connecting Rod Assembly Note.)
14	Lower connecting rod bearing
15	Connecting rod cap


MECHANICAL [WL-3]

Main Bearing Cap Assembly Note


1. Apply clean engine oil to the bolt threads and seat faces of the lower cylinder block bolts.
2. Tighten the bolts in two or three steps in the order shown in the figure.

Tightening procedure

- (1) 14.5—34.5 N·m {1.5—3.5 kgf·m, 11—25 ft·lbf}
 - (2) 74.0—82.0 N·m {7.6—8.3 kgf·m, 55—60 ft·lbf}
 - (3) Loosen all the bolts (until bolts are torque-free).
 - (4) 14.5—34.5 N·m {1.5—3.5 kgf·m, 11—25 ft·lbf}
 - (5) 42.5—45.5 N·m {4.4—4.6 kgf·m, 32—33 ft·lbf}
3. Put a paint mark on each bolt head.
 4. Using the marks as a reference, tighten the bolts by turning each 90° — 105° as in Step 2.




DBG110AEB071



DBG110AEBR72

Piston, Connecting Rod, Piston Pin Assembly Note


1. Install one piston pin clip.
2. Assemble the piston and connecting rod in the direction indicated in the figure.
3. Apply clean engine oil to the piston pin.
4. Install the piston pin until the pin contacts the clip as shown. If the pin cannot be installed easily, heat the piston.



DPE110ZE1R18

Piston Ring Assembly Note

1. Install the oil ring.
2. Install the second ring with tapered face side upward.
3. Install the top ring with tapered face side upward.



DBG110AEBR96

01


Piston, Connecting Rod Assembly Note

1. Insert the piston and connecting rod assembly into the cylinder with the F mark facing the front of the engine.
2. Tighten the connecting rod cap nuts in two or three steps.

Tightening torque


26.5—31.5 N·m {2.8—3.2 kgf·m, 20—23 ft·lbf}

3. Put a paint mark on each nut.



DBG110AEBR95

4. Using the marks as a reference, tighten the nuts by turning each 82.5°—97.5°




DBG110AEBR73

MECHANICAL [WL-3]

CYLINDER BLOCK ASSEMBLY (II) [WL-3]

1. Assemble in the order indicated in the table.

DCF011002000W11



DBG110AEBR41


1	Oil pump body
2	Control plunger
3	Plunger spring
4	Plug
5	Driven gear
6	Oil pump cover (See 01-10A-37 Oil Pump Cover Assembly Note.)
7	Rear cover, end plate (See 01-10A-37 Rear Cover, End Plate Assembly Note.)
8	End plate (See 01-10A-37 Rear Cover, End Plate Assembly Note.)
9	Flywheel (See 01-10A-38 Flywheel Assembly Note.)
10	Timing gear case (See 01-10A-38 Timing Gear Case Assembly Note.)

11	Fuel injection pump
12	Timing gear (See 01-10A-38 Timing Gear, Fuel Injection Pump Gear Assembly Note.)
13	Fuel injection pump gear (See 01-10A-38 Timing Gear, Fuel Injection Pump Gear Assembly Note.)
14	Oil pump
15	Timing gear cover (See 01-10A-40 Timing Gear Cover Assembly Note.)
16	Fuel injection pump pulley (See 01-10A-41 Fuel Injection Pump Pulley Assembly Note.)
17	Crankshaft pulley (See 01-10A-41 Crankshaft Pulley Assembly Note.)

MECHANICAL [WL-3]

Oil Pump Cover Assembly Note

1. Tighten the bolts in two or three steps in the order shown in the figure.




DBG110AEB053

01

Rear Cover, End Plate Assembly Note

1. Apply soapy water along the perimeter of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Tap the oil seal in evenly by using the **SST** and a hammer.
4. To ensure that the oil seal is installed correctly, measure the distance between the end of the rear cover and the face of the oil seal.


Rear oil seal press-in amount
0—0.5 mm {0—0.01 in}



DBG110BEB059

5. Apply silicone sealant to the rear cover as shown in the figure.

Thickness
φ2.0—3.0 mm {0.079—0.118 in}




DBG110AEBR55

6. Apply silicone sealant to the rear cover as shown in the figure.

Thickness
φ2.0—3.0 mm {0.079—0.118 in}

7. Install the end plate.




DBG110AEBR94

MECHANICAL [WL-3]

Flywheel Assembly Note

1. Hold the crankshaft using the **SST**.
2. Tighten the bolts in the order shown in the figure.




DBG110AEB056

Timing Gear Case Assembly Note

1. Install the new O-ring.
2. Apply silicone sealant to the timing gear case as shown in the figure. Do not apply sealant to the O-ring.


Thickness

$\phi 2.0-3.0$ mm {0.079—0.118 in}



DBG110AEBR57


3. Tighten the bolts in two or three steps in the order shown in the figure.



DBG110AEBR58

Timing Gear, Fuel Injection Pump Gear Assembly Note


1. Put a paint mark on the chip cut gear of the fuel injection pump gear.



DBG110AEB9R3


MECHANICAL [WL-3]

- Put a paint mark on the 11th and 12th teeth of the helical gear counting clockwise from the chip cut gear.




DBG110AEBR83

- Verify that the 11th and 12th teeth of fuel injection pump gear (helical gear) and the teeth of the scissors gear are aligned, then put a paint mark on the scissors gear.
- Set the No.1 cylinder to TDC of compression.



DBG110AEBR82

- Rotate the flywheel ring gear from TDC to approximately 30° BTDC (13 teeth on the gear).




DBG110AEBR59

- Align the timing marks. For the fuel injection pump gear, align the timing mark as shown in the figure (View A).

Note


- The helical gears except for the fuel injection pump gear have a punch mark as the timing mark. The timing mark of each gear can be aligned easily if the paint mark is made on the punch mark.



DBG110AEBR60


MECHANICAL [WL-3]

7. Remove the lock bolt.



DBG110AEBR97

8. Tighten the bolts using the **SST**.




DBG110AEB061

Timing Gear Cover Assembly Note

1. Apply soapy water along the perimeter of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Tap the oil seal in evenly using the **SST** and a hammer.
4. To ensure that the oil seal is installed correctly, measure the distance between the end of the timing gear cover and the face of the oil seal.

Front oil seal press-in amount
0—0.4 mm {0—0.01 in}


Fuel injection pump oil seal press-in amount
0—0.4 mm {0—0.01 in}



DBG110BEBR12

5. Apply silicone sealant to the timing gear cover as shown in the figure.


Thickness
φ2.0—3.0 mm {0.079—0.118 in}



DBG110AEBR63

MECHANICAL [WL-3]


6. Tighten the bolts in two or three steps in the order shown in the figure.



01

Fuel Injection Pump Pulley Assembly Note


1. Install the fuel injection pump pulley using the SST.




Crankshaft Pulley Assembly Note

Caution

- The CKP sensor plate is a very important part for engine operation control; any deformation of the plate may disable the operation control.
- When disassembling/assembling the crankshaft pulley, be very careful not to deform the plate by interference with other parts or improper handling.



1. Install the crankshaft pulley using the SST.




MECHANICAL [WL-3]

CYLINDER BLOCK ASSEMBLY (III) [WL-3]

DCF011002000W12

1. Assemble in the order indicated in the table.




DBG110AEBR90

1	Oil pipe (See 01-10A-43 Oil Pipe Assembly Note.)
2	Oil strainer

3	Oil pan (See 01-10A-43 Oil Pan Assembly Note.)
4	Oil drain plug

Oil Pipe Assembly Note

1. Tighten the bolts in two or three steps in the order shown in the figure.



DBG110AEBR89


01

Oil Pan Assembly Note

1. Apply silicone sealant to the oil pan as shown in the figure.

Thickness

$\phi 2.0-3.0 \text{ mm } \{0.08-0.118 \text{ in}\}$




DBG110AEBR87

2. Tighten the oil pan bolts A as shown in the figure.

Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause bolt hole damage.

3. Tighten the remaining oil pan bolts in several passes.




CHU0111W004

MECHANICAL [WL-3]

CYLINDER HEAD ASSEMBLY (I) [WL-3]

DCF011002000W13

1. Assemble in the order indicated in the table.



DBG110AEBR27

1	Valve seal (See 01-10A-44 Valve Seal Assembly Note.)
2	Valve
3	Lower valve spring seat
4	Valve spring


5	Upper valve spring seat
6	Valve keeper (See 01-10A-45 Valve Keeper Assembly Note.)
7	Pivot

Valve Seal Assembly Note

1. Assemble the **SSTs** so that depth L is as specified.

Depth L
15.6 mm {0.614 in}


2. Press the valve seal onto the valve guide by hand.



DPE110ZE1R26

MECHANICAL [WL-3]


3. Tap the **SST** using a plastic hammer until its lower end touches the cylinder head.



DGB110AEB111

Valve Keeper Assembly Note

1. Install the valve keeper using the **SST**.



DBG110AEB029


01

MECHANICAL [WL-3]

CYLINDER HEAD ASSEMBLY (II) [WL-3]

DCF011002000W14

1. Assemble in the order indicated in the table.




1	Cylinder head gasket (See 01-10A-47 Cylinder Head Gasket Assembly Note.)
2	Cylinder head (See 01-10A-48 Cylinder Head Assembly Note.)
3	Blind cover (See 01-10A-48 Blind Cover Assembly Note.)
4	Water outlet pipe
5	ECT sensor
6	Water temperature sender unit (See 01-10A-48 Water Temperature Sender Unit Assembly Note.)

7	Rocker arm (See 01-10A-49 Rocker Arm Assembly Note.)
8	Camshaft
9	Camshaft cap (See 01-10A-49 Camshaft Cap Assembly Note.)
10	Seal plate (See 01-10A-50 Seal Plate Assembly Note.)
11	Camshaft pulley (See 01-10A-50 Camshaft Pulley Assembly Note.)

MECHANICAL [WL-3]

Cylinder Head Gasket Assembly Note

1. Measure the piston topping of all the cylinders.




DPE110ZE1R02

2. Choose the gasket according to each measured piston topping.

Cylinder head gasket select table

Piston topping (mm {in})	Cylinder head gasket identification mark
0.205—0.325 {0.081—0.127}	
0.265—0.385 {0.105—0.151}	
0.325—0.445 {0.128—0.175}	




DPE110ZE1R01

3. Apply silicone sealant to the cylinder block as shown in the figure.

Thickness

φ2.0—3.0 mm {0.079—0.118 in}



DBG110AEBR17

01

MECHANICAL [WL-3]


Cylinder Head Assembly Note

1. Before installing the cylinder head bolts, inspect their length. (See 01-10A-28 BOLT INSPECTION [WL-3].)
2. Apply clean engine oil to the threads and the seat face of each bolt and install them.
3. Tighten the cylinder head bolts in the order indicated in the figure in several passes.

Tightening torque

29 N·m {3.0 kgf·m, 2.1 ft·lbf}

4. Retighten the bolts in the order shown in the figure until all the bolts are tightened to 29 N·m {3.0 kgf·m, 2.1 ft·lbf}.




DBG110AEB018

5. Put a paint mark on each bolt head.
6. Using the marks as a reference, tighten the cylinder head bolts by turning each 90°—105° in the order indicated in Step 3.
7. Further tighten each bolt by turning another 90°—105° in the order indicated in Step 3.
8. Tighten the bolts A.

Tightening torque

17.6—19.6 N·m {1.8—1.9 kgf·m, 13—14 ft·lbf}




DBG110AEB019

Blind Cover Assembly Note

1. Apply silicone sealant to the blind cover as shown in the figure.

Thickness


φ1.5—2.5 mm {0.059—0.098 in}



DBG110AEBR23

Water Temperature Sender Unit Assembly Note

1. Apply silicone sealant to the thread of the water temperature sender unit as shown in the figure.




DBG110AEB022

Rocker Arm Assembly Note

1. If new rocker arm is used, set dimension A as follows.

Dimension A

0.0—4.0 mm {0.0—0.15 in}




DBG110AEB030

01

Camshaft Cap Assembly Note

1. Apply silicone sealant to the front camshaft cap mounting surfaces as indicated in the figure. Avoid getting sealant onto the camshaft journal, camshaft oil seal surface, and camshaft thrust surface.




DBG110AEB031

2. Tighten the camshaft cap bolts gradually in three or four steps in the order shown in the figure.

Caution

- Because there is little camshaft thrust clearance, the camshaft must be held horizontally while it is installed. Otherwise, excessive force will be applied to the thrust area, causing burrs on the thrust receiving area of the cylinder head journal. To avoid this, the following procedure must be observed.




DBG110AEB032

3. Apply soapy water along the perimeter of the new oil seal.
4. Push the oil seal slightly in by hand.
5. Tap the oil seal lightly into the cylinder head using the SST and a hammer.
6. To ensure that the oil seal is installed correctly, measure the distance between the end of the cylinder head and the face of the oil seal.

Camshaft oil seal press-in amount

0.5—1.0 mm {0.02—0.03 in}




DPE110ZE1R41

MECHANICAL [WL-3]

Seal Plate Assembly Note

1. Tighten the seal plate bolts in the order indicated in the figure.




DBG110AEB020

Camshaft Pulley Assembly Note

1. Install the camshaft pulley on the camshaft with the knock pin fitted into the hole at the timing mark.

Timing mark
WL




DBG110AEBR85

2. Hold the camshaft using a wrench on the cast hexagon and tighten the pully lock bolt.

Caution

- Do not move the camshaft from this position because it can cause the valve and piston to contact each other and damage them.




DBG110AEB021

MECHANICAL [WL-3]

TIMING BELT ASSEMBLY [WL-3]

DCF011002000W15

1. Assemble in the order indicated in the table.



DBG110AEBR07

1	Timing belt (See 01-10A-52 Timing Belt, Tensioner, Tensioner Spring Assembly Note.)
2	Tensioner, tensioner spring (See 01-10A-52 Timing Belt, Tensioner, Tensioner Spring Assembly Note.)
3	Pulley plate

4	Timing belt cover (See 01-10A-52 Timing Belt Cover Assembly Note.)
5	Cylinder head cover (See 01-10A-52 Cylinder Head Cover Assembly Note.)
6	Vacuum pump
7	Water pump


MECHANICAL [WL-3]

Timing Belt, Tensioner, Tensioner Spring Assembly Note

Caution

- Overtensioning of the timing belt can cause breakage of the belt and the camshaft.


1. Align the timing marks as shown in the figure.
2. Verify that the fuel injection pump attaching bolts and nuts are tightened to the specified torque. This must be done to prevent overtensioning of the timing belt after it has been installed.
3. Install the timing belt.
4. Install the tensioner, tensioner spring, and the lock bolt.
5. Tighten the tensioner lock bolt.
6. Turn the crankshaft clockwise twice, and align the timing marks. If they are not aligned, remove the timing belt and repeat from Step 1.
7. Loosen the tensioner lock bolt to apply tension to the belt. Do not apply tension other than that of the tensioner spring.
8. Tighten the tensioner lock bolt. Be sure the tensioner does not move together with the bolt rotation.



DBG110AEBR11

Timing Belt Cover Assembly Note


1. Tighten the timing belt cover bolts in the order shown in the figure.



DBG110AEB012

Cylinder Head Cover Assembly Note

1. Before installing the cylinder head cover, inspect the valve clearance. (See 01-10A-29 VALVE CLEARANCE INSPECTION [WL-3].)
2. Apply silicone sealant to the cylinder head as shown.



DBG110AEB013

3. Tighten cylinder head cover bolts A and B.


Tightening torque

1.5—2.9 N·m {16—29 kgf·cm, 14—25 in·lbf}

4. Tighten the cylinder head cover bolts in the order shown in the figure.

Tightening torque

4.9—8.8 N·m {50—89 kgf·cm, 44—77 in·lbf}



DBG110AEBR14

01-10B MECHANICAL [WL-C, WE-C]

ENGINE MOUNTING [WL-C, WE-C] ...	01-10B-2
ENGINE DISMOUNTING	
[WL-C, WE-C]	01-10B-3
TIMING BELT DISASSEMBLY	
[WL-C, WE-C]	01-10B-4
CYLINDER HEAD DISASSEMBLY (I)	
[WL-C, WE-C]	01-10B-6
CYLINDER HEAD DISASSEMBLY (II)	
[WL-C, WE-C]	01-10B-8
CYLINDER BLOCK DISASSEMBLY (I)	
[WL-C, WE-C]	01-10B-9
CYLINDER BLOCK DISASSEMBLY (II)	
[WL-C, WE-C]	01-10B-10
CYLINDER BLOCK DISASSEMBLY (III)	
[WL-C, WE-C]	01-10B-15
CYLINDER HEAD INSPECTION/REPAIR	
[WL-C, WE-C]	01-10B-16
VALVE INSPECTION [WL-C, WE-C] ...	01-10B-17
VALVE GUIDE INSPECTION	
[WL-C, WE-C]	01-10B-18
VALVE GUIDE REPLACEMENT	
[WL-C, WE-C]	01-10B-18
VALVE SEAT INSPECTION/REPAIR	
[WL-C, WE-C]	01-10B-19
VALVE SPRING INSPECTION	
[WL-C, WE-C]	01-10B-20
CAMSHAFT INSPECTION	
[WL-C, WE-C]	01-10B-20
CAMSHAFT OIL CLEARANCE	
INSPECTION [WL-C, WE-C]	01-10B-21
CAMSHAFT END PLAY INSPECTION	
[WL-C, WE-C]	01-10B-21
CYLINDER BLOCK	
INSPECTION/REPAIR [WL-C, WE-C] .	01-10B-22
DUAL-MASS FLYWHEEL	
INSPECTION [WL-C, WE-C]	01-10B-22
OIL JET VALVE, NOZZLE	
INSPECTION [WL-C, WE-C]	01-10B-25
PISTON INSPECTION	
[WL-C, WE-C]	01-10B-25
PISTON CLEARANCE	
INSPECTION/REPAIR	
[WL-C, WE-C]	01-10B-25

PISTON RING CLEARANCE	
INSPECTION [WL-C, WE-C]	01-10B-26
PISTON PIN CLEARANCE	
INSPECTION [WL-C, WE-C]	01-10B-26
CRANKSHAFT INSPECTION	
[WL-C, WE-C]	01-10B-27
CRANKSHAFT OIL CLEARANCE	
INSPECTION/REPAIR	
[WL-C, WE-C]	01-10B-28
CRANKSHAFT END PLAY	
INSPECTION/REPAIR	
[WL-C, WE-C]	01-10B-28
CONNECTING ROD	
INSPECTION [WL-C, WE-C]	01-10B-29
CONNECTING ROD OIL CLEARANCE	
INSPECTION/REPAIR	
[WL-C, WE-C]	01-10B-29
CONNECTING ROD SIDE CLEARANCE	
INSPECTION [WL-C, WE-C]	01-10B-29
PISTON AND CONNECTING	
ROD INSPECTION [WL-C, WE-C]	01-10B-30
BALANCE SHAFT INSPECTION	
[WL-C, WE-C]	01-10B-30
BOLT INSPECTION [WL-C, WE-C]	01-10B-31
VALVE CLEARANCE INSPECTION	
[WL-C, WE-C]	01-10B-31
VALVE CLEARANCE ADJUSTMENT	
[WL-C, WE-C]	01-10B-32
GEAR CLEARANCE INSPECTION	
[WL-C, WE-C]	01-10B-33
PLUNGER SPRING INSPECTION	
[WL-C, WE-C]	01-10B-33
CYLINDER BLOCK ASSEMBLY (I)	
[WL-C, WE-C]	01-10B-34
CYLINDER BLOCK ASSEMBLY (II)	
[WL-C, WE-C]	01-10B-37
CYLINDER BLOCK ASSEMBLY (III)	
[WL-C, WE-C]	01-10B-43
CYLINDER HEAD ASSEMBLY (I)	
[WL-C, WE-C]	01-10B-45
CYLINDER HEAD ASSEMBLY (II)	
[WL-C, WE-C]	01-10B-47
TIMING BELT ASSEMBLY	
[WL-C, WE-C]	01-10B-51


MECHANICAL [WL-C, WE-C]

ENGINE MOUNTING [WL-C, WE-C]


1. Install the **SST** to the cylinder head using the bolt (99784 1020 or **M10X1.25, 8T**, length **20mm {0.79 in}**) as shown in the figure.

Tightening torque


43.1—60.8 N·m {4.40—6.10 kgf·m, 31.8—44.8 ft·lbf}




2. Suspend the engine using the **SST**.



3. Install the **SST** (arms) to the holes as shown in the figure, and hand tighten the **SST** (bolts).




4. Assemble the **SSTs** (bolts, nuts and plate) to the specified positions.



MECHANICAL [WL-C, WE-C]


5. Adjust the **SST** (bolts) so that 20 mm {0.79 in} or more of thread is exposed.
6. Align the **SSTs** (plate and arms) so that they are parallel by adjusting the **SSTs** (bolts and nuts).
7. Tighten the **SSTs** (bolts and nuts) to affix the **SST** firmly.



8. Mount the engine on the **SST** (engine stand).

Warning

- The self-locking brake system for the engine stand may not operate if the engine is held in an unbalanced position. This could lead to sudden, rapid movement of the engine and mounting stand handle and cause serious injury. Never hold the engine in an unbalanced position, and always grasp the rotating handle firmly when turning the engine.



9. Remove the **SST** (303-050 (49 UN30 3050)).
10. Drain the engine oil into a container.
11. Install the drain plug using new washer.

Tightening torque

29.4—41.2 N·m {3.0—4.2 kgf·m, 22—30 ft·lbf}

ENGINE DISMOUNTING [WL-C, WE-C]

1. Dismount in the reverse order of mounting.


DCF011002000W17

MECHANICAL [WL-C, WE-C]

TIMING BELT DISASSEMBLY [WL-C, WE-C]

DCF011002000W18

1. Disassemble in the order shown in the figure.




DBG110BEB014

1	Water pump
2	Vacuum pump
3	Timing belt cover
4	Tensioner (See 01-10B-5 Tensioner Disassembly Note.)

5	Idler
6	Timing belt (See 01-10B-5 Timing Belt Disassembly Note.)
7	Injector
8	Cylinder head cover

Tensioner Disassembly Note

1. Turn the crankshaft clockwise and align the timing marks as shown in the figure.




DBG110WB98

2. Turn the auto tensioner counterclockwise using an Allen wrench. (Rotate the auto tensioner with a force of **39 N·m {4.0 kgf·m, 28.8 ft·lbf}** or less.)
3. Insert a fixing pin of approx. **6 mm {0.24 in}** diameter into hole A to secure the auto tensioner.
4. Remove the bolts in the order of B and C, then remove the auto tensioner.


Note

- If the rod projects suddenly while removing the auto tensioner, the air flows into the pressure chamber and the rod could move slightly. If this occurs, bleed the air from the pressure chamber using the following procedure.



DBG110BE033

5. Assemble the auto tensioner to the engine.
6. Turn the auto tensioner with a force of **39 N·m {4.0 kgf·m, 28.8 ft·lbf}** or less using an Allen wrench, then turn it back slowly. Repeat this procedure several times.
7. Verify that the rod has resistance when it is in the most projected position. If there is no resistance, repeat the above procedure.




DBG110BW999

Timing Belt Disassembly Note

Caution

- The following will damage the timing belt and shorten its life; forcefully twisting it, turning it inside out, or getting oil or grease on it.
- After removing the timing belt, do not move the crankshaft and/or camshaft pulley from this position because it can cause the valve and piston to contact and damage them.

1. Mark the timing belt rotation on the belt for proper reinstallation.




DBG110BW003

MECHANICAL [WL-C, WE-C]

CYLINDER HEAD DISASSEMBLY(I) [WL-C, WE-C]

DCF011002000W19

1. Disassemble in the order shown in the figure.



DBG110BEB062

1	Camshaft pulley (See 01-10B-7 Camshaft Pulley Disassembly Note.)
2	Seal plate
3	Camshaft cap upper (See 01-10B-7 Camshaft Cap Upper Disassembly Note.)
4	Camshaft


5	Camshaft cap Lower
6	ECT sensor
7	Cylinder head (See 01-10B-7 Cylinder Head Disassembly Note.)
8	Cylinder head gasket

Camshaft Pulley Disassembly Note

1. Hold the camshaft using a wrench on the cast hexagon.

Caution

- Do not move the camshaft from this position because it can cause the valve and piston to contact each other and damage them.




DBG110BEB082

01

Camshaft Cap Upper Disassembly Note

1. Loosen the camshaft cap bolts in three or four steps in the order shown in the figure.




DBG110BEB083

Camshaft Disassembly Note

1. Before removing the camshaft, inspect the camshaft oil clearance. (See 01-10B-21 CAMSHAFT OIL CLEARANCE INSPECTION [WL-C, WE-C].)

Cylinder Head Disassembly Note

1. Remove bolts A.
2. Loosen the cylinder head bolts in two or three steps in the order shown in the figure.




DBG110BEB084

MECHANICAL [WL-C, WE-C]

CYLINDER HEAD DISASSEMBLY (II) [WL-C, WE-C]

DCF011002000W20

1. Disassemble in the order shown in the figure.




DBG110BEB016

1	Rocker arm
2	Pivot
3	Valve cap
4	Valve keeper (See 01-10B-8 Valve Keeper Disassembly Note.)
5	Upper valve spring seat

6	Valve spring
7	Valve
8	Valve seal (See 01-10B-9 Valve Seal Disassembly Note.)
9	Lower valve spring seat
10	Water outlet pipe

Valve Keeper Disassembly Note

1. Remove the valve keeper using the SST.




DBG110BEB011

MECHANICAL [WL-C, WE-C]

Valve Seal Disassembly Note

1. Remove the valve seal using the SST.




DBG110BEB085

01

CYLINDER BLOCK DISASSEMBLY (I) [WL-C, WE-C]

1. Disassemble in the order shown in the figure.

DCF011002000W21



DBG110BEB075


1	Oil drain plug
2	Oil pan (See 01-10B-10 Oil Pan Disassembly Note.)

3	Oil strainer
4	Oil pipe

MECHANICAL [WL-C, WE-C]

Oil Pan Disassembly Note

1. Remove the oil pan using a separator tool.




DBG110BEB086

CYLINDER BLOCK DISASSEMBLY (II) [WL-C, WE-C]

1. Disassemble in the order shown in the figure.

DCF011002000W22



DBG110BEB019

MECHANICAL [WL-C, WE-C]


1	Crankshaft pulley (See 01-10B-11 Crankshaft Pulley Disassembly Note.)
2	Seal plate
3	Supply pump pulley (See 01-10B-11 Supply Pump Pulley Disassembly Note.)
4	Timing gear cover (See 01-10B-11 Timing Gear Cover Disassembly Note.)
5	Oil pump
6	Supply pump gear (See 01-10B-12 Supply Pump Gear Disassembly Note.)
7	Timing gear
8	Supply pump

9	Timing gear case (See 01-10B-14 Timing Gear Case Disassembly Note.)
10	Dual-mass flywheel (See 01-10B-14 Dual-mass flywheel Disassembly Note.)
11	End plate
12	Rear cover (See 01-10B-14 Rear Cover Disassembly Note.)
13	Seal plate
14	Oil pump cover
15	Driven gear
16	Plug
17	Plunger spring
18	Control plunger
19	Oil pump body

01

Crankshaft Pulley Disassembly Note


1. Remove the crankshaft pulley using the SST.



DBG110BEB064

Supply Pump Pulley Disassembly Note


1. Remove the supply pump pulley using the SST.



DBG110BEB055

Timing Gear Cover Disassembly Note


1. Remove the timing gear cover using a separator tool.



DBG110BEB087

MECHANICAL [WL-C, WE-C]


2. Remove the oil seal using a screwdriver protected with a rag,



DBG110BEB088

Supply Pump Gear Disassembly Note

1. Set the No.1 cylinder to TDC of compression.
2. Rotate the flywheel ring gear from TDC to approximately 30° BTDC (about 13 teeth on the gear).




DBG110BEB089

3. Verify that the end-gap (V groove) of the timing gear case and the chip cut gear of the fuel injection pump gear are aligned.

Note

- If the chip cut gear is hard to find, move the supply pump gear on notch back and forth, then check the chip cut gear.



DBG110BEB90

MECHANICAL [WL-C, WE-C]

4. Fix the scissors gear to the supply pump gear using a lock bolt (M6×1.0; length under the bolt head is approximately 16 mm {0.63 in}).

Warning


- When removing the supply pump gear, be sure to secure the scissors gear to the supply pump gear using a lock bolt (M6×1.0; length under the bolt head is approximately 16 mm {0.63 in}). Otherwise, the scissors gear will rotate with the spring force, causing personal injury.

Caution

- When removing the supply pump gear, be sure to secure the scissors gear to the supply pump gear using a lock bolt (M6×1.0; length under the bolt head is approximately 16 mm {0.63 in}) to prevent the scissors gear from rotating with the spring force. Otherwise, the scissors gear will not align with the supply pump gear, and the supply pump gear with the scissors gear will not engage with the idler gear.


Note

- The supply pump gear with a scissors gear has a lock bolt hole.




DBG110BEB091

5. Hold the crankshaft using the **SST** and loosen the gear nut.



DBG110BEB092

6. Remove the supply pump gear using the **SST** and bolt (M6X1.0, Length 30mm {1.18 in}).




DBG110BEB093

01

MECHANICAL [WL-C, WE-C]

Timing Gear Case Disassembly Note


1. Remove the timing gear case using the separator tool.



DBG110BEB094

Dual-mass flywheel Disassembly Note


1. Remove the Dual-mass flywheel using the SST.



DBG110BEB034

Rear Cover Disassembly Note

1. Remove the oil seal using a screwdriver protected with a rag.



DBG110BEB095


MECHANICAL [WL-C, WE-C]

CYLINDER BLOCK DISASSEMBLY (III) [WL-C, WE-C]

DCF011002000W23

1. Disassemble in the order shown in the figure.

01



DBG110BEB021

1	Balance shaft
2	Connecting rod cap (See 01-10B-16 Connecting Rod Cap Disassembly Note)
3	Lower connecting rod bearing
4	Piston, connecting rod (See 01-10B-16 Piston, Connecting Rod Disassembly Note)
5	Upper connecting rod bearing
6	Piston ring
7	Piston pin clip
8	Piston pin (See 01-10B-16 Piston Pin Disassembly Note)

9	Piston
10	Connecting rod
11	Main bearing cap (See 01-10B-16 Main Bearing Cap Disassembly Note)
12	Lower main bearing, lower thrust bearing
13	Crankshaft (See 01-10A-16 Crankshaft Disassembly Note)
14	Upper main bearing, upper thrust bearing
15	Oil jet valve, nozzle
16	Cylinder block

MECHANICAL [WL-C, WE-C]

Connecting Rod Cap Disassembly Note


1. Before removing the connecting rod cap, inspect the connecting rod side clearance. (See 01-10B-29 CONNECTING ROD SIDE CLEARANCE INSPECTION [WL-C, WE-C].)

Piston, Connecting Rod Disassembly Note

1. Before removing the piston and connecting rod, inspect the connecting rod oil clearance. (See 01-10B-29 CONNECTING ROD OIL CLEARANCE INSPECTION/REPAIR [WL-C, WE-C].)
2. Inspect the oscillation torque. (See 01-10B-30 PISTON AND CONNECTING ROD INSPECTION [WL-C, WE-C].)

Piston Pin Disassembly Note


1. Remove the piston pin using the SST.



DBG110BEB096

Main Bearing Cap Disassembly Note

1. Before removing the main bearing cap, inspect the crankshaft end play. (See 01-10B-28 CRANKSHAFT END PLAY INSPECTION/REPAIR [WL-C, WE-C].)
2. Loosen the main bearing cap bolts in two or three steps in the order shown in the figure.



DBG110BEB079

Crankshaft Disassembly Note

1. Before removing the crankshaft, inspect the main journal oil clearance. (See 01-10B-28 CRANKSHAFT OIL CLEARANCE INSPECTION/REPAIR [WL-C, WE-C].)

CYLINDER HEAD INSPECTION/REPAIR [WL-C, WE-C]

DCF011010100W02


1. Inspect the cylinder head surface for cracks. Replace the cylinder head if necessary.
2. Inspect for the following and repair or replace.
 - (1) Sunken valve seats
 - (2) Excessive camshaft oil clearance and end play
3. Measure the cylinder head for distortion in the seven directions as shown in the figure.

Maximum cylinder head distortion

X distortion: 0.02 mm {0.0008 in} max.

Y distortion: 0.05 mm {0.0020 in} max.

4. If the cylinder head distortion exceeds the maximum, replace the cylinder head. Do not attempt to repair a cylinder head by milling or grinding.




DBG110BEB080

5. Measure the manifold contact surface distortion as shown in the figure.

Maximum manifold contact surface distortion
0.05 mm {0.002 in} max.

6. If the distortion exceeds the maximum, grind the surface or replace the cylinder head.

Maximum manifold contact surface grinding
0.15 mm {0.0059 in} max.



DBG110BEB140

VALVE INSPECTION [WL-C, WE-C]

1. Measure the valve head margin thickness of each valve. Replace the valve if necessary.

Standard valve margin thickness
IN: 1.55—1.85 mm {0.061—0.072 in}
EX: 1.80—2.10 mm {0.070—0.082 in}

2. Measure the length of each valve. Replace the valve if necessary.


Standard valve length
IN: 111.65—112.25 mm {4.394—4.413 in}
EX: 111.6—112.2 mm {4.390—4.409 in}

Minimum valve length
IN: 111.50 mm {4.390 in}
EX: 111.45 mm {4.388 in}


3. Measure the stem diameter of each valve in the X and Y directions at the three points (A, B, and C) shown in the figure. Replace the valve if necessary.

Standard valve stem diameter
IN: 5.970—5.985 mm {0.2350—0.2356 in}
EX: 5.965—5.980 mm {0.2348—0.2354 in}

Minimum valve stem diameter
IN: 5.920 mm {0.2330 in}
EX: 5.915 mm {0.2328 in}



DBG110BEB098




DBG110BEB099

MECHANICAL [WL-C, WE-C]

VALVE GUIDE INSPECTION [WL-C, WE-C]


1. Measure the inner diameter of each valve guide in the X and Y directions at the three points (A, B, and C) shown in the figure. Replace the valve guide if necessary.

Standard valve guide inner diameter
6.025—6.045 mm {0.2372—0.2379 in}



2. Measure the protrusion height (dimension A) of each valve guide without lower valve spring seat. Replace the valve guide if necessary.


Standard valve guide height
IN: 15.0—15.5 mm {0.59—0.61 in}
EX: 17.0—17.5 mm {0.67—0.69 in}



VALVE GUIDE REPLACEMENT [WL-C, WE-C]

Valve Guide Removal


- Remove the valve guide from the combustion chamber side using the SST.



Valve Guide Installation

1. Mark the dimension L position on the valve guide.

Depth L
IN: 15.0—15.5 mm {0.59—0.61 in}
EX: 17.0—17.5 mm {0.67—0.68 in}




MECHANICAL [WL-C, WE-C]

2. When the valve guide nears the dimension L position while it is being tapped in, verify the dimension L position again with vernier calipers to prevent deviation in insertion.
3. Verify that the valve guide projection height is within the specification.

Standard valve guide height

IN: 15.0—15.5 mm {0.59—0.61 in}

EX: 17.0—17.5 mm {0.67—0.68 in}



DBG110BEB045


01

VALVE SEAT INSPECTION/REPAIR [WL-C, WE-C]

1. Measure the seat contact width. If necessary, resurface the valve seat using a 45° valve seat cutter and/or resurface the valve face.

Standard valve seat contact width

1.3—1.9 mm {0.052—0.074 in}




DCF011010102W02

2. Verify that the valve seating position is at the center of the valve face.
 1. If the seating position is too high, correct the valve seat using a 60° cutter, and then a 45° cutter.
 2. If the seating position is too low, correct the valve seat using a 30° cutter, and a 45° cutter.

Valve seat angle

IN: 45°

EX: 45°



DBG110AEB078

3. Measure the receded amount from the cylinder head surface. If it exceeds the maximum, replace the cylinder head.

Standard valve recession


IN: 0.79—1.27 mm {0.039—0.050 in}

EX: 0.84—1.32 mm {0.033—0.051 in}

Maximum valve recession

IN: 1.68 mm {0.066 in}

EX: 1.73 mm {0.062 in}



DBG110AEB112

MECHANICAL [WL-C, WE-C]

VALVE SPRING INSPECTION [WL-C, WE-C]


1. Apply a pressing force to the pressure spring and check the spring height. Replace the valve spring if necessary.

Valve spring installation pressing force
172.9—195.6 N {15.67—17.74 kgf, 34.48—
39.02 lbf}


Valve spring installation height
39.0 mm {1.53 in}

2. Measure the amount the valve spring is out-of-square. Replace the valve spring if necessary.

Maximum valve spring out-of-square
2.0° (1.60mm {0.062 in})



DBG0110AEB11




DBG0110AEB079

CAMSHAFT INSPECTION [WL-C, WE-C]

1. Set the No.1 and No.5 journals on V-blocks. Measure the camshaft runout. Replace the camshaft if necessary.

Maximum camshaft runout
0.03 mm {0.001 in} max.




DBG0110AEB114

2. Measure the cam lobe height at the two points as shown in the figure. Replace the camshaft if necessary.

Standard cam lobe height
IN: 42.067—42.167 mm {1.6561—1.6601 in}
EX: 41.949—42.049 mm {1.6515—1.6554 in}

Minimum cam lobe height
IN: 41.717 mm {1.6424 in}
EX: 41.599 mm {1.6377 in}



DBG0110AEB080

MECHANICAL [WL-C, WE-C]

3. Measure the journal diameters in the X and Y directions at the two points (A and B) as shown in the figure. Replace the camshaft if necessary.

Standard cam journal diameter

No.1: 31.940—31.965 mm {1.2575—1.2582 in}

No.2—No.4: 25.910—25.935 mm {1.0201—1.0210 in}


No.5: 25.940—25.965 mm {1.0212—1.0222 in}

Minimum cam journal diameter

No.1: 31.890 mm {1.2555 in}

No.2—No.4: 25.860 mm {1.0181 in}

No.5: 25.890 mm {1.0193 in}



DBG110AEB081

01

CAMSHAFT OIL CLEARANCE INSPECTION [WL-C, WE-C]

DCF011012420W05

1. Position a plastigage on top of the journals in the axial direction.
2. Install the camshaft cap. (See 01-10B-49 Camshaft Cap Upper Assembly Note.)
3. Remove the camshaft cap. (See 01-10B-7 Camshaft Cap Upper Disassembly Note.)
4. Measure the oil clearance. Replace the cylinder head if necessary.

Standard camshaft clearance

No.1: 0.035—0.081 mm {0.0014—0.0031 in}

No.2—4: 0.065—0.111 mm {0.0026—0.0043 in}


No.5: 0.056—0.081 mm {0.0014—0.0031 in}

Maximum camshaft clearance

No.1: 0.12 mm {0.0047 in}

No.2—4: 0.15 mm {0.0059 in}

No.5: 0.16 mm {0.0063 in}



DBG110BEB053

CAMSHAFT END PLAY INSPECTION [WL-C, WE-C]

DCF011012420W06

1. Install the camshaft cap. (See 01-10B-49 Camshaft Cap Upper Assembly Note.)
2. Measure the camshaft end play. Replace the cylinder head or camshaft if necessary.


Standard camshaft end play

0.030—0.160 mm {0.0012—0.0062 in}

Maximum camshaft end play

0.20 mm {0.0078 in}

3. Remove the camshaft cap. (See 01-10B-7 Camshaft Cap Upper Disassembly Note.)



DBG110BEB109

MECHANICAL [WL-C, WE-C]

CYLINDER BLOCK INSPECTION/REPAIR [WL-C, WE-C]


DCF011010300W02

1. Measure the distortion of the cylinder block top surface in the seven directions as shown in the figure. Replace if necessary.

Maximum cylinder block distortion

X direction: 0.02 mm {0.0008 in}

Y direction: 0.05 mm {0.002 in}



DBG110AEB115

2. Measure the cylinder bore using the cylinder gauge. Measurement positions are in the X and Y directions at **83 mm {3.27 in}** (WL-C) or **88 mm {3.46 in}** (WE-C) below the top surface of the cylinder.

- If the cylinder bore exceeds the wear limit, replace the cylinder block or rebore the cylinder and install the oversized pistons so that the specified piston-to-cylinder clearance is obtained.

Note

- Base the boring diameter on the diameter of an oversized piston. All cylinders must be the same diameter.

Cylinder bore size [WL-C]

Standard: 93.000—93.022 mm {3.6615—3.6622 in}

0.25 {0.01} oversize: 93.250—93.272 mm {3.6713—3.6721 in}

0.50 {0.02} oversize: 93.500—93.522 mm {3.6811—3.6819 in}

Cylinder bore size [WE-C]


Standard: 96.000—96.022 mm {3.6615—3.6622 in}

0.25 {0.01} oversize: 96.250—96.272 mm {3.7893—3.7902 in}

0.50 {0.02} oversize: 96.500—96.522 mm {3.7992—3.8000 in}

Cylinder bore wear limit

0.15 mm {0.0059 in}



DBG110BEB047

DUAL-MASS FLYWHEEL INSPECTION [WL-C, WE-C]

DCF011011500W01

Caution


- Do not rework the flywheel if it is distorted.
- Do not clean the dual mass flywheel with any kind of fluid. Clean the flywheel with a dry cloth only.
- Do not clean the gap between the primary and secondary mass. Only clean the bolt connection surface and the clutch surface.

Note

- Correct slight scratches and discoloration using sandpaper.
- Inspect the runout of the surface that contacts the clutch disc with the flywheel installed to the crankshaft.

1. Inspect the flywheel.

- Cracks
- Worn ring gear teeth
- Chipped or cracked ring gear teeth
- Surface that contacts the clutch disc for scratches, nicks, and discoloration.
- If there is any malfunction, replace the flywheel.




C3U0510W004

2. Verify that the center of the flywheel does not move.

(1) Rotate the flywheel or attempt to move it up and down, and left and right to verify that the center of the flywheel does not move.


- If there is any movement as indicated by the arrows in the figure, replace the flywheel with a new one.



B3E0510W055

3. Verify that the secondary mass rotates by 15 teeth or more.

- If it rotates by 15 teeth or more, replace the dual-mass flywheel.



D3E510ZW8001

4. Inspect for locating dowels touching the primary mass of the flywheel.

Caution

- **Make sure that the three locating dowels are installed.**


- If the locating dowels are touching the primary mass of the flywheel, replace the flywheel with a new one.

5. Visually inspect the secondary mass.


- If there is any damage, replace the dual-mass flywheel.

6. Visually inspect the ring gear on the dual-mass flywheel.

- If there is any damage, replace the dual-mass flywheel.




B3E0510W056



D3E510ZW8002

MECHANICAL [WL-C, WE-C]

7. Inspect the welded area of the dual-mass flywheel for grease leakage.
- If there is grease leakage, replace the dual-mass flywheel.




B3E0510W057

8. Inspect the dual-mass flywheel runout.

Flywheel maximum runout
1.5 mm {0.059 in}


- If it is more than the maximum specification, replace the dual-mass flywheel.



D3E510ZW8007


9. Inspect the dual-mass flywheel for the amount of guide pin projection.

- If not within the specification, replace the dual-mass flywheel.



D3E510ZW8005

10. Rotate the secondary mass left and right and verify that it rotates within a range of five teeth without resistance.
- If there is any malfunction, replace the dual-mass flywheel.
11. Inspect the dual-mass flywheel for cracks.
- If there are cracks, replace the dual-mass flywheel.



D3E510ZW8006

MECHANICAL [WL-C, WE-C]

OIL JET VALVE, NOZZLE INSPECTION [WL-C, WE-C]


DCF011010730W02

1. Apply compressed air to oil jet valve A and verify that air passes through oil jet valve B. If not, replace the oil jet valve.

Oil jet air pressure

137.6—196.4 kPa {1.4—2.0 kgf/cm², 20—28 psi}

2. Check the oil jet nozzle for clogs. Replace the nozzle if necessary.



DBG110AEB085

PISTON INSPECTION [WL-C, WE-C]

DCF011011010W06

1. Measure the outer diameter of each piston at right angle (90°) to the piston pin, 20 mm {0.79 in} below the oil ring land lower edge.

Piston diameter [WL-C]

Standard: 92.918—92.944 mm {3.6582—3.6592 in}

0.25 {0.010} oversize: 93.153—93.179 mm {3.6675—3.6684 in}


0.50 {0.020} oversize: 93.403—93.429 mm {3.6773—3.6782 in}

Piston diameter [WE-C]

Standard: 95.918—95.944 mm {3.7763—3.7773 in}

0.25 {0.010} oversize: 96.153—96.179 mm {3.7856—3.7865 in}

0.50 {0.020} oversize: 96.403—96.429 mm {3.7954—3.7964 in}



DBG110AEBR86

PISTON CLEARANCE INSPECTION/REPAIR [WL-C, WE-C]

DCF011011010W07

1. Measure the piston-to-cylinder clearance. Replace the piston or rebore the cylinders to fit the oversized piston if necessary.

Standard piston clearance

0.071—0.089 mm {0.0015—0.0022 in}

Maximum piston clearance

0.15 mm {0.0059 in}

2. If the piston is replaced, the piston rings must also be replaced.

MECHANICAL [WL-C, WE-C]

PISTON RING CLEARANCE INSPECTION [WL-C, WE-C]

1. Measure the piston ring-to-ring land clearance around the entire circumference. Replace the piston and piston ring if necessary.


Standard piston ring clearance [WL-C]

Top: 0.06—0.10 mm {0.0024—0.0039 in}
Second: 0.04—0.08 mm {0.0016—0.0031 in}
Oil: 0.02—0.06 mm {0.0012—0.0023 in}

Standard piston ring clearance [WE-C]

Top: 0.06—0.10 mm {0.0024—0.0039 in}
Second: 0.04—0.08 mm {0.0016—0.0031 in}
Oil: 0.02—0.06 mm {0.0008—0.0023 in}

Maximum piston ring clearance
0.15 mm {0.0059 in}



DCF011011010W08
DBG110AEB116

2. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.
3. Measure each piston ring end gap with a feeler gauge. Replace the piston ring, if necessary.


Standard piston ring end gap [WL-C]

Top: 0.22—0.32 mm {0.0087—0.0125 in}
Second: 0.49—0.64 mm {0.0193—0.0251 in}
Oil: 0.22—0.52 mm {0.0087—0.0204 in}

Standard piston ring end gap [WE-C]

Top: 0.23—0.33 mm {0.0091—0.0129 in}
Second: 0.50—0.65 mm {0.0197—0.0255 in}
Oil: 0.22—0.52 mm {0.0087—0.0204 in}

Maximum piston ring end gap
1.0 mm {0.039 in}




DBG110AEB087

PISTON PIN CLEARANCE INSPECTION [WL-C, WE-C]

1. Measure each piston pin bore diameter in the X and Y directions at the four points (A, B, C, and D) as shown in the figure.

Standard piston pin bore diameter

33.997—34.007 mm {1.3384—1.3388 in}




DCF011011010W09
DBG110AEB088

2. Measure each connecting rod small end inner diameter in the X and Y directions as shown in the figure.

Standard connecting rod small end inner diameter

34.012—34.033 mm {1.3391—1.3398 in}



DBG110AEB117

MECHANICAL [WL-C, WE-C]

3. Measure each piston pin diameter in the X and Y directions at the four points (A, B, C and D) as shown in the figure.


Standard piston pin diameter
33.994—34.000 mm {1.3384—1.3385 in}

4. Calculate the piston pin-to-piston pin bore clearance. Replace the piston and/or piston pin if necessary.

Standard piston pin-to-piston pin bore clearance
-0.003—0.013 mm {-0.0001—0.0005 in}

5. Calculate the connecting rod small end-to-piston pin clearance. Replace the connecting rod or piston pin.

Standard connecting rod small end-to-piston pin clearance
0.012—0.039 mm {0.00048—0.0015 in}




DBG110AEB118

CRANKSHAFT INSPECTION [WL-C, WE-C]

1. Measure the crankshaft runout. Replace the crankshaft if necessary.

Maximum crankshaft runout
0.05 mm {0.002 in}




DCF011011301W04

DBG110AEB089

2. Measure the journal diameter in the X and Y directions at the two points (A and B) as shown in the figure. Replace the crankshaft or grind the journal and install the undersize bearing if necessary.

Main journal diameter [No.1,2,4,5]

Standard: 66.937—66.955 mm {2.6354—2.6360 in}
0.25 {0.010} undersize: 66.687—66.705 mm {2.6255—2.6261 in}
0.50 {0.020} undersize: 66.437—66.455 mm {2.6157—2.6163 in}
0.75 {0.030} undersize: 66.187—66.205 mm {2.6058—2.6064 in}



DBG110AEB090

Main journal diameter [No.3]

Standard: 66.920—66.938 mm {2.6347—2.6353 in}
0.25 {0.010} undersize: 66.670—66.688 mm {2.6367—2.6373 in}
0.50 {0.020} undersize: 66.420—66.438 mm {2.6150—2.6156 in}
0.75 {0.030} undersize: 66.170—66.188 mm {2.6052—2.6058 in}

Main journal wear limit
0.05 mm {0.002 in}

Main journal out-of-round
0.03 mm {0.001 in}

MECHANICAL [WL-C, WE-C]

Crank pin diameter [WL-C]

Standard: 54.940—54.955 mm {2.1630—2.1635 in}
0.25 {0.010} undersize: 54.690—54.705 mm {2.1532—2.1537 in}
0.50 {0.020} undersize: 54.440—54.455 mm {2.1434—2.1438 in}
0.75 {0.030} undersize: 54.190—54.205 mm {2.1335—2.1340 in}

Crank pin diameter [WE-C]

Standard: 56.940—56.955 mm {2.2417—2.2423 in}
0.25 {0.010} undersize: 56.690—56.705 mm {2.2318—2.2324 in}
0.50 {0.020} undersize: 56.440—56.455 mm {2.2220—2.2226 in}
0.75 {0.030} undersize: 56.190—56.205 mm {2.2122—2.2128 in}

Crank pin wear limit
0.05 mm {0.0020 in}

Crank pin out-of-round
0.03 mm {0.0012 in}

CRANKSHAFT OIL CLEARANCE INSPECTION/REPAIR [WL-C, WE-C]

DCF011011301W05

1. Position a plastigage on top of the journals in the axial direction.
2. Install the main bearing cap. (See 01-10B-35 Main Bearing Cap Assembly Note.)
3. Remove the main bearing cap. (See 01-10B-16 Main Bearing Cap Disassembly Note.)
4. Measure the main journal oil clearance. If the clearance exceeds the maximum, replace the main bearing or grind the main journal and install the undersize bearings so that the specified oil clearance is obtained.

Standard main journal clearance

No.1, 2, 4, 5: 0.027—0.045 mm {0.0010—0.0017 in}
No.3: 0.044—0.062 mm {0.0017—0.0024 in}

Maximum main journal clearance
0.08 mm {0.003 in}

Main bearing thickness

Standard: 2.006—2.021 mm {0.0789—0.0794 in}
0.25 {0.010} undersize: 2.124—2.134 mm {0.0836—0.0838 in}
0.50 {0.020} undersize: 2.249—2.259 mm {0.0885—0.0888 in}
0.75 {0.030} undersize: 2.374—2.384 mm {0.0934—0.0937 in}

CRANKSHAFT END PLAY INSPECTION/REPAIR [WL-C, WE-C]

DCF011011301W06

1. Install the main bearing cap. (See 01-10B-35 Main Bearing Cap Assembly Note.)
2. Measure the crankshaft end play. If the end play exceeds the maximum, replace the thrust bearing or grind the crankshaft and install an oversized bearing so that the specified end play is obtained.


Standard crankshaft end play

0.040—0.282 mm {0.0016—0.0111 in}

Maximum crankshaft end play
0.3 mm {0.01 in}

Thrust bearing thickness

Standard: 2.455—2.505 mm {0.0967—0.986 in}
0.35 {0.010} oversize: 2.630—2.680 mm {0.1036—0.1055 in}



DBG110AEB120

3. Remove the main bearing cap. (See 01-10B-16 Main Bearing Cap Disassembly Note.)

MECHANICAL [WL-C, WE-C]

01

CONNECTING ROD INSPECTION [WL-C, WE-C]


1. Measure each connecting rod for bending and distortion. Replace the connecting rod if necessary.

Connecting rod bending
0.075 mm {0.0030 in} max./50 mm {1.968 in}

Connecting rod distortion
0.18 mm {0.0070 in} max./50 mm {1.968 in}

Connecting rod center-to-center distance [WL-C]
162.96—163.04 mm {6.416—6.418 in}

Connecting rod center-to-center distance [WE-C]
157.96—158.04 mm {6.219—6.222 in}




CONNECTING ROD OIL CLEARANCE INSPECTION/REPAIR [WL-C, WE-C]

1. Position a plastigage on top of the journals in the axial direction.
2. Install the connecting rod cap. (See 01-10B-36 Piston, Connecting Rod Assembly Note.)
3. Remove the connecting rod cap.
4. Measure the crankpin oil clearance. If the clearance exceeds the maximum, replace the connecting rod bearing or grind the crankpin and use undersized bearings so that the specified clearance is obtained.

Standard connecting rod oil clearance
0.025—0.052 mm {0.0009—0.0020 in}

Maximum connecting rod oil clearance
0.08 mm {0.003 in}

Connecting rod bearing thickness
Standard: 1.507—1.516 mm {0.0592—0.0595 in}
0.25 {0.010} undersize: 1.624—1.634 mm {0.0638—0.0642 in}
0.50 {0.020} undersize: 1.749—1.759 mm {0.0687—0.0691 in}
0.75 {0.030} undersize: 1.874—1.884 mm {0.0737—0.0740 in}




CONNECTING ROD SIDE CLEARANCE INSPECTION [WL-C, WE-C]

1. Install the connecting rod cap. (See 01-10B-36 Piston, Connecting Rod Assembly Note.)
2. Measure the connecting rod large end side clearance. Replace the connecting rod and cap if necessary.

Standard connecting rod side clearance
0.110—0.262 mm {0.0043—0.0103 in}

Maximum connecting rod side clearance
0.35 mm {0.014 in}


3. Remove the connecting rod cap.



MECHANICAL [WL-C, WE-C]

PISTON AND CONNECTING ROD INSPECTION [WL-C, WE-C]

- Check the oscillation torque as shown. If the large end does not drop by its own weight, replace the piston or the piston pin.



DCF011011010W10

DBG110AEB093

BALANCE SHAFT INSPECTION [WL-C, WE-C]

- Install the balance shaft and tighten the thrust plate fitting bolt.

DCF011010300W03


Tightening torque

7.85—10.8 N·m {80—110 kgf·m, 70—95 in·lbf}

- Measure the balance shaft end play. Replace the balance shaft and/or cylinder block if necessary.

Balance shaft Standard end play

0.04—0.16 mm {0.002—0.006 in}



DBG110AEB094


- Measure the journal diameters in the X and Y directions at the two points (A and B) as shown in the figure. Replace the balance shaft if necessary.

Standard diameter

Front: 41.945—41.960 mm {1.6514—1.6519 in}

Center: 39.945—39.960 mm {1.5727—1.5732 in}

Rear: 37.975—37.990 mm {1.4951—1.4956 in}




DBG110AEB095

- Measure the balance shaft bore in the cylinder block. Calculate the balance shaft-to-balance shaft bore clearance. Replace the balance shaft and/or cylinder block if necessary.

Standard clearance

Front, rear: 0.050—0.115 mm {0.0020—0.0045 in}

Center: 0.080—0.145 mm {0.0032—0.0057 in}



DBG110AEB096

MECHANICAL [WL-C, WE-C]

BOLT INSPECTION [WL-C, WE-C]

- Measure the length of each bolt. Replace the bolt if necessary.

Cylinder head bolt length

Bolt head mark W

Standard length: 101.2—101.8 mm {3.985—4.007 in}

Maximum length: 102.5 mm {4.035 in}

Bolt head mark N

Standard length: 113.2—113.8 mm {4.457—4.480 in}

Maximum length: 114.5 mm {4.508 in}

Bolt head mark I

Standard length: 149.0—150.0 mm {5.866—5.905 in}

Maximum length: 150.5 mm {5.925 in}

Main bearing cap bolt length


Standard length: 84.7—85.3 mm {3.34—3.35 in}

Maximum length: 86.0 mm {3.39 in}

Connecting rod cap bolt length

Standard length: 55.45—56.05 mm {2.19—2.20 in}

Maximum length: 56.75 mm {2.23 in}




DCF011010135W02

DBG110AEB097

01

VALVE CLEARANCE INSPECTION [WL-C, WE-C]

1. Remove the cylinder head cover.
2. Turn the crankshaft and align the timing mark so that the piston of the No. 1 or No. 4 cylinders is at TDC of compression.
3. Measure valve clearances A with the No. 1 cylinder at TDC of compression, and those of B with the No. 4 cylinder at TDC of compression.
 - If it is not within the specification, adjust and recheck the valve clearance. (See 01-10B-32 VALVE CLEARANCE ADJUSTMENT [WL-C, WE-C].)




DBG110BEB023

Valve clearance [Engine cold]

IN: 0.10—0.16 mm {0.0040—0.0062 in}

EX: 0.17—0.23 mm {0.0067—0.0090 in}

4. Turn the crankshaft one full turn and measure the remaining valve clearances. Adjust if necessary.
5. Install the cylinder head cover.



DBG110BTBR5

MECHANICAL [WL-C, WE-C]


VALVE CLEARANCE ADJUSTMENT [WL-C, WE-C]

DCF011012111W06


Caution

- Loosening the locknut and the adjust screw while the cam lobe is not pressing down the rocker arm will damage the claw of the rocker arm. When loosening the locknut and the adjust screw, rotate the crankshaft clockwise and be sure that the cam lobe presses down the rocker arm firmly as shown in the figure.

- Remove the cylinder head cover.
- Turn the crankshaft and align the timing mark so that the piston of the No. 1 or No. 4 cylinders is at TDC of compression.
- Adjust the valve clearances A with the No.1 cylinder at TDC of compression, and those of B with the No.4 cylinder at TDC of compression.



DBG110BTBRR6



DBG110BEB023

Valve clearance [Engine cold]


IN: 0.10—0.16 mm {0.0040—0.0062 in}

EX: 0.17—0.23 mm {0.0067—0.0090 in}

Tightening torque (lock nut)

20—24 N·m {2.1—2.4 kgf·m, 15—17 ft·lbf}

- Turn the crankshaft one full turn and measure the remaining valve clearances. Adjust if necessary.
- Install the cylinder head cover.



DBG110BTBRR5

MECHANICAL [WL-C, WE-C]


GEAR CLEARANCE INSPECTION [WL-C, WE-C]

DCF011019220W02

1. Measure the following clearance.
 - If it exceeds the maximum specification, replace the gear and/or pump body.

Standard oil pump tip clearance
0.10—0.19 mm {0.0040—0.0074 in}


Maximum oil pump tip clearance
0.20 mm {0.008 in}



DBG110AEB101

Standard oil pump side clearance
0.04—0.09 mm {0.0016—0.0035 in}

Maximum oil pump side clearance
0.15 mm {0.0059 in}




DBG110AEB102

PLUNGER SPRING INSPECTION [WL-C, WE-C]

DCF011014116W02

1. Apply pressing force to the pressure spring and check the spring height. Replace the plunger spring if necessary.

Standard plunger spring length
43.8 mm {1.72 in}



DBG110AEB103


01

MECHANICAL [WL-C, WE-C]

CYLINDER BLOCK ASSEMBLY (I) [WL-C, WE-C]

1. Assemble in the order indicated in the table.

DCF011002000W24



DBG110BEB052

1	Cylinder block
2	Oil jet valve, nozzle
3	Upper main bearing, upper thrust bearing
4	Crankshaft
5	Lower main bearing, lower thrust bearing
6	Main bearing cap (See 01-10B-35 Main Bearing Cap Assembly Note.)
7	Connecting rod (See 01-10B-35 Piston, Connecting Rod, Piston Pin Assembly Note.)

8	Piston (See 01-10B-35 Piston, Connecting Rod, Piston Pin Assembly Note.)
9	Piston pin (See 01-10B-35 Piston, Connecting Rod, Piston Pin Assembly Note.)
10	Piston pin clip
11	Piston ring (See 01-10B-36 Piston Ring Assembly Note.)
12	Upper connecting rod bearing

01-10B-34

MECHANICAL [WL-C, WE-C]

13	Piston, connecting rod (See 01-10B-36 Piston, Connecting Rod Assembly Note.)
14	Lower connecting rod bearing

15	Connecting rod cap
16	Balance shaft


01

Main Bearing Cap Assembly Note


1. Apply clean engine oil to the bolt threads and seat faces of the lower cylinder block bolts.
2. Tighten the bolts in two or three steps in the order shown in the figure.

Tightening procedure

- (1) 14.5—34.5 N·m {1.5—3.5 kgf·m, 11—25 ft·lbf}
 - (2) 74.0—82.0 N·m {7.6—8.3 kgf·m, 55—60 ft·lbf}
 - (3) Loosen all the bolts (until bolts are torque-free).
 - (4) 14.5—34.5 N·m {1.5—3.5 kgf·m, 11—25 ft·lbf}
 - (5) 42.5—45.5 N·m {4.4—4.6 kgf·m, 32—33 ft·lbf}
3. Put a paint mark on each bolt head.
 4. Using the marks as a reference, tighten the bolts by turning each 90°—105° as in Step 2.




DBG110AEB271



DBG110AEB072

Piston, Connecting Rod, Piston Pin Assembly Note

1. Install one piston pin clip.
2. Assemble the piston and connecting rod in the direction indicated in the figure.
3. Apply clean engine oil to the piston pin.
4. Install the piston pin until the pin contacts the clip as shown. If the pin cannot be installed easily, heat the piston.




DPE110ZE1R18

MECHANICAL [WL-C, WE-C]

Piston Ring Assembly Note

1. Install the oil ring.
2. Install the second ring with R mark side upward.
3. Install the top ring with tapered face side upward.



DBG110AEBR96


Piston, Connecting Rod Assembly Note

1. Insert the piston and connecting rod assembly into the cylinder with the F mark facing the front of the engine.
2. Tighten the connecting rod cap bolts in two or three steps.


Tightening torque

46.5—51.5 N·m {4.8—5.2 kgf·m, 34.3—37.9 ft·lbf}

3. Put a paint mark on each bolt.
4. Using the marks as a reference, tighten the bolts by turning each 82.5°—97.5°



DBG110AEBRR5




DBG110AEBRR3

MECHANICAL [WL-C, WE-C]

CYLINDER BLOCK ASSEMBLY (II) [WL-C, WE-C]

DCF011002000W25

1. Assemble in the order indicated in the table.



DBG110BEB001

1	Oil pump body
2	Control plunger
3	Plunger spring
4	Plug
5	Driven gear
6	Oil pump cover (See 01-10B-38 Oil Pump Cover Assembly Note.)
7	Rear cover (See 01-10B-38 Rear Cover, End Plate Assembly Note.)

8	End plate (See 01-10B-38 Rear Cover, End Plate Assembly Note.)
9	Dual-mass flywheel (See 01-10B-39 Dual-mass Flywheel Assembly Note.)
10	Seal plate
11	Timing gear case (See 01-10B-39 Timing Gear Case Assembly Note.)
12	Supply pump


MECHANICAL [WL-C, WE-C]

13	Timing gear (See 01-10B-40 Timing Gear, Supply Pump Gear Assembly Note.)
14	Supply pump gear (See 01-10B-40 Timing Gear, Supply Pump Gear Assembly Note.)
15	Oil pump
16	Timing gear cover (See 01-10B-42 Timing Gear Cover Assembly Note.)

17	Supply pump pulley (See 01-10B-42 Supply Pump Pulley Assembly Note.)
18	Seal plate
19	Crankshaft pulley (See 01-10B-43 Crankshaft Pulley Assembly Note.)

Oil Pump Cover Assembly Note

1. Tighten the bolts in two or three steps in the order shown in the figure.




DBG110AEB053

Rear Cover, End Plate Assembly Note

1. Apply soapy water along the perimeter of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Tap the oil seal in evenly using the **SST** and a hammer
4. To ensure that the oil seal is installed correctly, measure the distance between the end of the rear cover and the face of the oil seal.


Rear oil seal press-in amount
0—0.5 mm {0—0.01 in}



DBG110BEB059

5. Apply silicone sealant to the rear cover as shown.

Thickness
φ2.0—3.0 mm {0.07—0.12 in}



DBG110BEB003


MECHANICAL [WL-C, WE-C]

6. Apply silicone sealant to the rear cover as shown in the figure.

Thickness

$\phi 2.0-3.0$ mm {0.07—0.12 in}

7. Install the end plate.




DBG110AEBR94

01

Dual-mass Flywheel Assembly Note

1. Hold the crankshaft using the SST.
2. Tighten the bolts in the order shown in the figure.




DBG110BEB051

Timing Gear Case Assembly Note

1. Install the new O-ring.
2. Apply silicone sealant to the timing gear case as shown in the figure. Do not apply sealant to the O-ring.


Thickness

$\phi 2.0-3.0$ mm {0.07—0.12 in}



DBG110BEB104

3. Tighten the bolts in two or three steps in the order shown in the figure.




DBG110BEB072


MECHANICAL [WL-C, WE-C]

Timing Gear, Supply Pump Gear Assembly Note


1. Put a paint mark on the chip cut gear of the supply pump gear.
2. Put a paint mark on the 10th and 11th teeth of the helical gear counting clockwise from the chip cut gear.
3. Verify that the 10th and 11th teeth of supply pump gear (helical gear) and the teeth of the scissors gear are aligned, then put a paint mark on the scissors gear.
4. Set the No.1 cylinder to TDC of compression.
5. Rotate the flywheel ring gear from TDC to approximately 30° BTDC (13 teeth on the gear).




DBG110AEBR93



DBG110BEB141



DBG110BEB103



DBG110AEBR59


MECHANICAL [WL-C, WE-C]

6. Align the timing marks. For the supply pump gear, align the timing mark as shown in the figure (View A).

Note


- The helical gears except for the supply pump gear have a punch mark as the timing mark. The timing mark of each gear can be aligned easily if the paint mark is made on the punch mark.

01




DBG110BEB078

7. Remove the lock bolt.



DBG110AEBR97

8. Tighten the bolts using the SST.



DBG110AEB061

MECHANICAL [WL-C, WE-C]

Timing Gear Cover Assembly Note

1. Apply soapy water along the perimeter of the new oil seal.
2. Push the oil seal slightly in by hand.
3. Tap the oil seal in evenly using the **SST** and a hammer.
4. To ensure that the oil seal is installed correctly, measure the distance between the end of the timing gear cover and the face of the oil seal.


Front oil seal press-in amount
0.0—0.40 mm {0.0—0.015 in}

Fuel injection pump oil seal press-in amount
0.0—0.40 mm {0.0—0.015 in}


5. Apply silicone sealant to the timing gear cover as shown.

Thickness
φ2.0—3.0 mm {0.079—0.118 in}


6. Tighten the bolts in two or three steps in the order shown in the figure.



DBG110BEB012




DBG110BEB071



DBG110BEB073

Supply Pump Pulley Assembly Note

1. Install the supply pump pulley using the **SST**.




DBG110BEB054

MECHANICAL [WL-C, WE-C]

Crankshaft Pulley Assembly Note

1. Install the crankshaft pulley using the SST.




DBG110BEB055

01

CYLINDER BLOCK ASSEMBLY (III) [WL-C, WE-C]

DCF011002000W26

1. Assemble in the order indicated in the table.



DBG110BEB074


1	Oil pipe (See 01-10B-44 Oil Pipe Assembly Note.)
2	Oil strainer

3	Oil pan (See 01-10B-44 Oil Pan Assembly Note.)
4	Oil drain plug

MECHANICAL [WL-C, WE-C]

Oil Pipe Assembly Note

1. Tighten the bolts in two or three steps in the order shown in the figure.



DBG110BEB076

Oil Pan Assembly Note

1. Apply silicone sealant to the oil pan as shown in the figure.


Thickness

$\phi 2.0-3.0$ mm {0.07—0.12 in}

2. Tighten the oil pan bolts A as shown in the figure.


Caution

- If the bolts are reused, remove the old sealant from the bolt threads. Tightening a bolt that has old sealant on it can cause bolt hole damage.



DBG110BEB056

3. Tighten the remaining oil pan bolts in several passes.




CHU0111W004

MECHANICAL [WL-C, WE-C]

CYLINDER HEAD ASSEMBLY (I) [WL-C, WE-C]

DCF011002000W27

1. Assemble in the order indicated in the table.



N·m { kgf·m, ft·lbf }

DBG110BEB065


1	Water outlet pipe
2	Lower valve spring seat
3	Valve seal (See 01-10B-46 Valve Seal Assembly Note.)
4	Valve
5	Valve spring
6	Upper valve spring seat

7	Valve keeper (See 01-10B-46 Valve Keeper Assembly Note.)
8	Valve cap
9	Pivot (See 01-10B-46 Pivot Assembly Note.)
10	Rocker arm (See 01-10B-46 Rocker Arm Assembly Note.)

MECHANICAL [WL-C, WE-C]


Valve Seal Assembly Note

1. Tap the **SST** using a plastic hammer.



Valve Keeper Assembly Note

1. Install the valve keeper using the **SST**.



Pivot Assembly Note


1. Apply adhesive to the thread of the pivot.

Rocker Arm Assembly Note

1. If a new rocker arm is used, set dimension A as follows.

Dimension A

0.0—4.0 mm {0.0—0.115 in}




MECHANICAL [WL-C, WE-C]

CYLINDER HEAD ASSEMBLY (II) [WL-C, WE-C]

DCF011002000W28

1. Assemble in the order indicated in the table.

01



DBG110BEB026

1	Cylinder head gasket (See 01-10B-48 Cylinder Head Gasket Assembly Note.)
2	Cylinder head (See 01-10B-48 Cylinder Head Assembly Note.)
3	ECT sensor
4	Camshaft cap lower (See 01-10B-49 Camshaft Cap Lower Assembly Note.)


5	Camshaft
6	Camshaft cap upper (See 01-10B-49 Camshaft Cap Upper Assembly Note.)
7	Seal plate (See 01-10B-50 Seal Plate Assembly Note.)
8	Camshaft pulley (See 01-10B-50 Camshaft Pulley Assembly Note.)

01-10B-47

MECHANICAL [WL-C, WE-C]

Cylinder Head Gasket Assembly Note

1. Measure the piston topping of all the cylinders.




DPE110ZE1R02

2. Choose the gasket according to each measured piston topping.

Cylinder head gasket select table

Piston topping (mm {in})	Cylinder head gasket identification mark
0.080—0.190 {0.004—0.007}	
0.135—0.255 {0.006—0.010}	
0.200—0.310 {0.008—0.012}	




DPE110BEBR94

3. Apply silicone sealant to the cylinder block as shown in the figure.

Thickness

ø2.0—3.0 mm {0.08—0.11 in}



DBG110BWBR9


Cylinder Head Assembly Note

1. Before installing the cylinder head bolts, inspect their length. (See 01-10B-31 BOLT INSPECTION [WL-C, WE-C].)
2. Apply clean engine oil to the threads and the seat face of each bolt and install them.
3. Tighten the bolts in two or three steps in the order shown in the figure.

Tighten torque

29 N·m {3.0 kgf·m, 21 ft·lbf}

4. Retighten the bolts in the order shown in the figure until all the bolts are tightened to 29 N·m {3.0 kgf·m, 2.1 ft·lbf}.



DBG110BEB027


5. Put a paint mark on each bolt head.
6. Using the marks as a reference, tighten the bolts by turning each 90° — 105° in the sequence shown.
7. Further tighten each bolt by turning another 90° — 105° .
8. Further tighten each bolt by turning another 90° — 105° .
9. Apply adhesive to the thread of bolt A.
10. Tighten bolts A.

Tighten torque

17.6—19.6 N·m {1.8—1.9 kgf·m, 13—14 ft·lbf}


Camshaft Cap Lower Assembly Note

1. Apply silicone sealant to the cylinder head as shown in the figure.



DBG110AWB311

01




DBG110BEB105

Camshaft Cap Upper Assembly Note

1. Apply adhesive to the front camshaft cap mounting surfaces as shown in the figure.
2. Tighten the camshaft cap bolts gradually in three or four steps in the order shown in the figure.


Caution

- Because there is little camshaft thrust clearance, the camshaft must be held horizontally while it is installed. Otherwise, excessive force will be applied to the thrust area, causing burrs on the thrust receiving area of the cylinder head journal. To avoid this, the following procedure must be observed.



DBG110BWB86

3. Apply soapy water along the perimeter of the new oil seal.
4. Push the oil seal slightly in by hand.




DBG110BEBR25

MECHANICAL [WL-C, WE-C]

5. Tap the oil seal lightly into the cylinder head using the **SST** and a hammer.
6. To ensure that the oil seal is installed correctly, measure the distance between the end of the cylinder head and the face of the oil seal.


Camshaft oil seal press-in amount
0.5—1.0 mm {0.020—0.039 in}



DPE110ZE1R41

Seal Plate Assembly Note


1. Tighten the seal plate bolts in the order indicated in the figure.



DBG110BEB041

Camshaft Pulley Assembly Note

1. Install the camshaft pulleys, positioning the knock pins as shown in the figure.




DBG110BWB85

2. Hold the camshaft using a wrench on the cast hexagon.

Caution

- Do not move the camshaft from this position because it can cause the valve and piston to contact each other and damage them.



DBG110BEBR17


MECHANICAL [WL-C, WE-C]

TIMING BELT ASSEMBLY [WL-C, WE-C]

DCF011002000W29

1. Assemble in the order indicated in the table.

01



1	Cylinder head cover
2	Injector

3	Auto tensioner (See 01-10B-52 Timing Belt Assembly Note.)
---	--

MECHANICAL [WL-C, WE-C]

4	Timing belt (See 01-10B-52 Timing Belt Assembly Note.)
5	Idler (See 01-10B-52 Timing Belt Assembly Note.)


6	Timing belt cover (See 01-10B-53 Timing Belt Cover Assembly Note.)
7	Water pump
8	Vacuum pump

Cylinder Head Cover Assembly Note

1. Apply silicone sealant to the cylinder head as shown in the figure.


Thickness

ø2.0—3.0 mm {0.08—0.11 in}



DBG110BWB84


2. Tighten the cylinder head cover bolts in the order shown in the figure.



DBG110BEB005


Timing Belt Assembly Note

1. Align the timing marks as shown in the figure.
2. Verify that the supply pump attaching bolts and nuts are tightened to the specified torque. This must be done to prevent over-tensioning of the timing belt after it has been installed.



DBG110BWB97

3. Install the tensioner and hand-tighten lock bolts A and B.
4. Install the timing belt.
5. Install the idler.
6. Tighten the lock bolt A.
7. Tighten the lock bolt B.
8. Remove the set pin from the tensioner.
9. Turn the crankshaft clockwise twice, and align the camshaft pulley timing marks. If they are not aligned, remove the timing belt and repeat from Step 1.




DBG110BWB96

MECHANICAL [WL-C, WE-C]


Timing Belt Cover Assembly Note

1. Tighten the timing belt cover bolts in the order shown in the figure.



DBG110BEB043

01



TECHNICAL DATA [WL-3]

01-50A TECHNICAL DATA [WL-3]

ENGINE TECHNICAL DATA [WL-3] 01-50A-1

01

ENGINE TECHNICAL DATA [WL-3]

DCF01500000W01

Item	Specification
Maximum cylinder head distortion	X distortion: 0.02 mm {0.0008 in} Y distortion: 0.05 mm {0.0020 in}
Maximum combustion chamber recession	0.02 mm {0.0008 in}
Maximum combustion chamber projection	0.005 mm {0.0002 in}
Combustion chamber crack	Limit: 10mm {0.39 in}
Maximum manifold contact surface distortion	0.05 mm {0.0020 in}
Maximum manifold contact surface grinding	0.15 mm {0.0059 in}
Standard valve margin thickness	IN: 1.5 mm {0.059 in} EX: 0.75 mm {0.030 in}
Standard valve length	IN: 111.6—112.1 mm {4.394—4.413 in} EX: 111.5—112.0 mm {4.390—4.409 in}
Minimum valve length	IN: 111.35 mm {4.384 in} EX: 111.25 mm {4.380 in}
Standard valve stem diameter	IN: 6.970—6.985 mm {0.2745—0.2749 in} EX: 6.965—6.980 mm {0.2743—0.2748 in}
Minimum valve stem diameter	IN: 6.920 mm {0.2724 in} EX: 6.915 mm {0.2722 in}
Standard valve guide inner diameter	7.025—7.045 mm {0.2766—0.2773 in}
Standard valve guide height	14.0—14.5 mm {0.552—0.570 in}
Standard valve seat contact width	IN: 1.6—2.2 mm {0.063—0.086 in} EX: 1.7—2.3 mm {0.067—0.090 in}
Valve seat angle	IN: 45° EX: 45°
Standard valve recession	IN: 0.61—1.09 mm {0.025—0.042 in} EX: 0.71—1.19 mm {0.028—0.046 in}
Maximum valve recession	IN: 1.50 mm {0.059 in} EX: 1.60 mm {0.063 in}
Valve spring installation pressing force	238—269 N {25—27 kgf, 54—60 lbf}
Valve spring installation height	35.5 mm {1.40 in}
Maximum valve spring out-of-square	2.0° (1.70mm {0.067 in})
Maximum camshaft runout	0.03 mm {0.0012 in}
Standard cam lobe height	IN: 42.400—42.500 mm {1.6692—1.6732 in} EX: 42.395—42.495 mm {1.6691—1.6730 in}
Minimum cam lobe height	IN: 42.050 mm {1.6555 in} EX: 42.045 mm {1.6711 in}
Standard cam journal diameter	No.1, No.5: 25.940—25.965 mm {1.0213—1.0222 in} No.2—No.4: 25.910—25.935 mm {1.0201—1.0210 in}
Minimum cam journal diameter	No.1, No.5: 25.890 mm {1.0193 in} No.2—No.4: 25.860 mm {1.0181 in}
Standard camshaft clearance	No.1, 5: 0.035—0.081 mm {0.0014—0.0031 in} No.2—4: 0.065—0.111 mm {0.0026—0.0043 in}
Maximum camshaft clearance	No.1, 5: 0.12 mm {0.0047 in} No.2—4: 0.15 mm {0.0059 in}
Standard camshaft end play	0.030—0.160 mm {0.0012—0.0062 in}
Maximum camshaft end play	0.20 mm {0.0079 in}
Maximum cylinder block distortion	X direction: 0.02 mm {0.0008 in} Y direction: 0.05 mm {0.0020 in}
Cylinder bore size	Standard: 93.000—93.022 mm {3.6615—3.6622 in} 0.25 {0.01} oversize: 93.250—93.272 mm {3.6713—3.6721 in} 0.50 {0.02} oversize: 93.500—93.522 mm {3.6811—3.6819 in}
Cylinder bore wear limit	0.15 mm {0.0059 in}
Oil jet air pressure	137.6—196.4 kPa {1.5—2.0 kgf/cm ² , 20—28 psi}

01-50A-1


TECHNICAL DATA [WL-3]

Item	Specification
Piston diameter	Standard: 92.951—92.977 mm {3.6595—3.6605 in} 0.25 {0.0098} oversize: 93.186—93.212 mm {3.6688—3.6697 in} 0.50 {0.02} oversize: 93.436—93.462 mm {3.6786—3.6795 in}
Standard piston clearance	0.055—0.073 mm {0.0022—0.0028 in}
Maximum piston clearance	0.15 mm {0.0059 in}
Standard piston ring clearance	Top: 0.06—0.10 mm {0.0024—0.0039 in} Second: 0.04—0.08 mm {0.0016—0.0031 in} Oil: 0.03—0.07 mm {0.0012—0.0027 in}
Maximum piston ring clearance	0.15 mm {0.0059 in}
Standard piston ring end gap	Top: 0.22—0.32 mm {0.0087—0.0125 in} Second: 0.32—0.47 mm {0.0126—0.0185 in} Oil: 0.22—0.37 mm {0.0087—0.0145 in}
Maximum piston ring end gap	1.0 mm {0.039 in}
Standard piston pin bore diameter	31.997—32.007 mm {1.2598—1.2601 in}
Standard connecting rod small end inner diameter	32.012—32.033 mm {1.2604—1.2611 in}
Standard piston pin diameter	31.994—32.000 mm {1.25961—1.25984 in}
Standard piston pin-to-piston pin bore clearance	−0.003—0.013 mm {−0.00011—0.00051 in}
Standard connecting rod small end-to-piston pin clearance	0.012—0.039 mm {0.00048—0.00153 in}
Maximum crankshaft runout	0.05 mm {0.0020 in}
Main journal diameter	Standard No.1, 2, 4, 5: 66.937—66.955 mm {2.6354—2.6360 in} No.3: 66.920—66.938 mm {2.6347—2.6353 in} 0.25 {0.01} undersize No.1, 2, 4, 5: 66.687—66.705 mm {2.6255—2.6261 in} No.3: 66.670—66.688 mm {2.6248—2.6255 in} 0.50 {0.02} undersize No.1, 2, 4, 5: 66.437—66.455 mm {2.6157—2.6163 in} No.3: 66.420—66.438 mm {2.6150—2.6156 in} 0.75 {0.03} undersize No.1, 2, 4, 5: 66.187—66.205 mm {2.6058—2.6064 in} No.3: 66.170—66.188 mm {2.6052—2.6058 in}
Main journal wear limit	0.05 mm {0.0020 in}
Main journal out-of-round	0.03 mm {0.0012 in}
Crank pin diameter	Standard: 54.940—54.955 mm {2.1630—2.1635 in} 0.25 {0.01} undersize: 54.690—54.705 mm {2.1532—2.1537 in} 0.50 {0.02} undersize: 54.440—54.455 mm {2.1434—2.1438 in} 0.75 {0.03} undersize: 54.190—54.205 mm {2.1335—2.134 in}
Crank pin wear limit	0.05 mm {0.0020 in}
Crank pin out-of-round	0.03 mm {0.0012 in}
Standard main journal clearance	No.1, 2, 4, 5: 0.027—0.046 mm {0.0011—0.0018 in} No.3: 0.044—0.063 mm {0.0018—0.0025 in}
Maximum main journal clearance	0.08 mm {0.0031 in}
Main bearing thickness	Standard: 2.006—2.021 mm {0.0790—0.0795 in} 0.25 {0.01} undersize: 2.124—2.134 mm {0.0837—0.0840 in} 0.50 {0.02} undersize: 2.249—2.259 mm {0.0886—0.0889 in} 0.75 {0.03} undersize: 2.374—2.384 mm {0.0935—0.0938 in}
Standard crankshaft end play	0.040—0.282 mm {0.0016—0.0111 in}
Maximum crankshaft end play	0.3 mm {0.012 in}
Thrust bearing thickness	Standard: 2.454—2.506 mm {0.0967—0.0986 in} 0.35 {0.014} oversize: 2.629—2.681 mm {0.1036—0.1055 in}
Maximum connecting rod bending	0.075 mm {0.0030 in} /50 mm {2.0 in}
Maximum connecting rod distortion	0.18 mm {0.0071 in} /50 mm {2.0 in}
Connecting rod center-to-center distance	151.96—152.04 mm {5.9827—5.9858 in}
Standard connecting rod bolt length	67.5—68.5 mm {2.66—2.69 in}
Maximum connecting rod bolt length	69 mm {2.7 in}
Standard connecting rod oil clearance	0.025—0.052 mm {0.0010—0.0020 in}
Maximum connecting rod oil clearance	0.08 mm {0.0031 in}

TECHNICAL DATA [WL-3]

Item	Specification
Connecting rod bearing thickness	Standard: 1.507—1.516 mm {0.0594—0.0596 in} 0.25 {0.01} undersize: 1.624—1.634 mm {0.0640—0.0643 in} 0.50 {0.02} undersize: 1.749—1.759 mm {0.0689—0.0692 in} 0.75 {0.03} undersize: 1.874—1.884 mm {0.0738—0.0741 in}
Standard connecting rod side clearance	0.110—0.262 mm {0.0044—0.0103 in}
Maximum connecting rod side clearance	0.35 mm {0.014 in}
Cylinder head bolt length	Bolt head mark W Standard length: 101.2—101.8 mm {3.985—4.007 in} Maximum length: 102.5 mm {4.035 in} Bolt head mark N Standard length: 113.2—113.8 mm {4.457—4.480 in} Maximum length: 114.5 mm {4.508 in}
Main bearing cap bolt length	Standard length: 84.7—85.3 mm {3.34—3.35 in} Maximum length: 86.0 mm {3.39 in}
Standard tensioner spring length	63.0 mm {2.48 in}
Valve clearance (engine cold)	IN: 0.05—0.15 mm {0.0020—0.0059 in} EX: 0.15—0.25 mm {0.0060—0.0098 in}
Fuel injection pump plunger adjustment value	0.95—1.05 mm {0.038—0.041 in}
Standard oil pump tip clearance	0.10—0.19 mm {0.0040—0.0074 in}
Maximum oil pump tip clearance	0.20 mm {0.0079 in}
Standard oil pump side clearance	0.04—0.09 mm {0.0016—0.0035 in}
Maximum oil pump side clearance	0.15 mm {0.0059 in}
Standard plunger spring length	43.8 mm {1.72 in}
Front oil seal press-in amount	0—0.4 mm {0—0.01 in}
Fuel injection pump oil seal press-in amount	0—0.4 mm {0—0.01 in}
Camshaft oil seal press-in amount	0.5—1.0 mm {0.02—0.03 in}

01



TECHNICAL DATA [WL-C, WE-C]

01-50B TECHNICAL DATA [WL-C, WE-C]

ENGINE TECHNICAL DATA

[WL-C, WE-C] 01-50B-1

01

ENGINE TECHNICAL DATA [WL-C, WE-C]

DCF01500000W02

Item	Specification
Maximum cylinder head distortion	X distortion: 0.02 mm {0.0008 in} max. Y distortion: 0.05 mm {0.0020 in} max.
Maximum manifold contact surface distortion	0.05 mm {0.002 in} max.
Maximum manifold contact surface grinding	0.15 mm {0.0059 in} max.
Standard valve margin thickness	IN: 1.55—1.85 mm {0.061—0.072 in} EX: 1.80—2.10 mm {0.070—0.082 in}
Standard valve length	IN: 111.65—112.25 mm {4.394—4.413 in} EX: 111.6—112.2 mm {4.390—4.409 in}
Minimum valve length	IN: 111.50 mm {4.390 in} EX: 111.45 mm {4.388 in}
Standard valve stem diameter	IN: 5.970—5.985 mm {0.2350—0.2356 in} EX: 5.965—5.980 mm {0.2348—0.2354 in}
Minimum valve stem diameter	IN: 5.920 mm {0.2330 in} EX: 5.915 mm {0.2328 in}
Standard valve guide inner diameter	6.025—6.045 mm {0.2372—0.2379 in}
Standard valve guide height	IN: 15.0—15.5 mm {0.59—0.61 in} EX: 17.0—17.5 mm {0.67—0.69 in}
Standard valve guide height	IN: 15.0—15.5 mm {0.59—0.61 in} EX: 17.0—17.5 mm {0.67—0.68 in}
Standard valve seat contact width	1.3—1.9 mm {0.052—0.074 in}
Valve seat angle	IN: 45° EX: 45°
Standard valve recession	IN: 0.79—1.27 mm {0.039—0.050 in} EX: 0.84—1.32 mm {0.033—0.051 in}
Maximum valve recession	IN: 1.68 mm {0.066 in} EX: 1.73 mm {0.062 in}
Valve spring installation pressing force	172.9—195.6 N {15.67—17.74 kgf, 34.48—39.02 lbf}
Valve spring installation height	39.0 mm {1.53 in}
Maximum valve spring out-of-square	2.0° (1.60mm {0.062 in})
Maximum camshaft runout	0.03 mm {0.001 in} max.
Standard cam lobe height	IN: 42.067—42.167 mm {1.6561—1.6601 in} EX: 41.949—42.049 mm {1.6515—1.6554 in}
Minimum cam lobe height	IN: 41.717 mm {1.6424 in} EX: 41.599 mm {1.6377 in}
Standard cam journal diameter	No.1: 31.940—31.965 mm {1.2575—1.2582 in} No.2—No.4: 25.910—25.935 mm {1.0201—1.0210 in} No.5: 25.940—25.965 mm {1.0212—1.0222 in}
Minimum cam journal diameter	No.1: 31.890 mm {1.2555 in} No.2—No.4: 25.860 mm {1.0181 in} No.5: 25.890 mm {1.0193 in}
Standard camshaft clearance	No.1: 0.035—0.081 mm {0.0014—0.0031 in} No.2—4: 0.065—0.111 mm {0.0026—0.0043 in} No.5: 0.056—0.081 mm {0.0014—0.0031 in}
Maximum camshaft clearance	No.1: 0.12 mm {0.0047 in} No.2—4: 0.15 mm {0.0059 in} No.5: 0.16 mm {0.0063 in}
Standard camshaft end play	0.030—0.160 mm {0.0012—0.0062 in}
Maximum camshaft end play	0.20 mm {0.0078 in}
Maximum cylinder block distortion	X direction: 0.02 mm {0.0008 in} Y direction: 0.05 mm {0.002 in}
Cylinder bore size [WL-C]	Standard: 93.000—93.022 mm {3.6615—3.6622 in} 0.25 {0.01} oversize: 93.250—93.272 mm {3.6713—3.6721 in} 0.50 {0.02} oversize: 93.500—93.522 mm {3.6811—3.6819 in}

01-50B-1

TECHNICAL DATA [WL-C, WE-C]

Item	Specification
Cylinder bore size [WE-C]	Standard: 96.000—96.022 mm {3.6615—3.6622 in} 0.25 {0.01} oversize: 96.250—96.272 mm {3.7893—3.7902 in} 0.50 {0.02} oversize: 96.500—96.522 mm {3.7992—3.8000 in}
Cylinder bore wear limit	0.15 mm {0.0059 in}
Flywheel maximum runout	1.5 mm {0.059 in}
Oil jet air pressure	137.6—196.4 kPa {1.4—2.0 kgf/cm ² , 20—28 psi}
Piston diameter [WL-C]	Standard: 92.918—92.944 mm {3.6582—3.6592 in} 0.25 {0.010} oversize: 93.153—93.179 mm {3.6675—3.6684 in} 0.50 {0.020} oversize: 93.403—93.429 mm {3.6773—3.6782 in}
Piston diameter [WE-C]	Standard: 95.918—95.944 mm {3.7763—3.7773 in} 0.25 {0.010} oversize: 96.153—96.179 mm {3.7856—3.7865 in} 0.50 {0.020} oversize: 96.403—96.429 mm {3.7954—3.7964 in}
Standard piston clearance	0.071—0.089 mm {0.0015—0.0022 in}
Maximum piston clearance	0.15 mm {0.0059 in}
Standard piston ring clearance [WL-C]	Top: 0.06—0.10 mm {0.0024—0.0039 in} Second: 0.06—0.08 mm {0.0024—0.0031 in} Oil: 0.02—0.06 mm {0.0012—0.0023 in}
Standard piston ring clearance [WE-C]	Top: 0.06—0.10 mm {0.0024—0.0039 in} Second: 0.04—0.08 mm {0.0016—0.0031 in} Oil: 0.02—0.06 mm {0.0008—0.0023 in}
Maximum piston ring clearance	0.15 mm {0.0059 in}
Standard piston ring end gap [WL-C]	Top: 0.22—0.32 mm {0.0087—0.0125 in} Second: 0.49—0.64 mm {0.0193—0.0251 in} Oil: 0.22—0.52 mm {0.0087—0.0204 in}
Standard piston ring end gap [WE-C]	Top: 0.23—0.33 mm {0.0091—0.0129 in} Second: 0.50—0.65 mm {0.0197—0.0255 in} Oil: 0.22—0.52 mm {0.0087—0.0204 in}
Maximum piston ring end gap	1.0 mm {0.039 in}
Standard piston pin bore diameter	33.997—34.007 mm {1.3384—1.3388 in}
Standard connecting rod small end inner diameter	34.012—34.033 mm {1.3391—1.3398 in}
Standard piston pin diameter	33.994—34.000 mm {1.3384—1.3385 in}
Standard piston pin-to-piston pin bore clearance	−0.003—0.013 mm {−0.0001—0.0005 in}
Standard connecting rod small end-to-piston pin clearance	0.012—0.039 mm {0.00048—0.0015 in}
Maximum crankshaft runout	0.05 mm {0.002 in}
Main journal diameter [No.1,2,4,5]	Standard: 66.937—66.955 mm {2.6354—2.6360 in} 0.25 {0.010} undersize: 66.687—66.705 mm {2.6255—2.6261 in} 0.50 {0.020} undersize: 66.437—66.455 mm {2.6157—2.6163 in} 0.75 {0.030} undersize: 66.187—66.205 mm {2.6058—2.6064 in}
Main journal diameter [No.3]	Standard: 66.920—66.938 mm {2.6347—2.6353 in} 0.25 {0.010} undersize: 66.670—66.688 mm {2.6367—2.6373 in} 0.50 {0.020} undersize: 66.420—66.438 mm {2.6150—2.6156 in} 0.75 {0.030} undersize: 66.170—66.188 mm {2.6052—2.6058 in}
Main journal wear limit	0.05 mm {0.002 in}
Main journal out-of-round	0.03 mm {0.001 in}
Crank pin diameter [WL-C]	Standard: 54.940—54.955 mm {2.1630—2.1635 in} 0.25 {0.010} undersize: 54.690—54.705 mm {2.1532—2.1537 in} 0.50 {0.020} undersize: 54.440—54.455 mm {2.1434—2.1438 in} 0.75 {0.030} undersize: 54.190—54.205 mm {2.1335—2.1340 in}
Crank pin diameter [WE-C]	Standard: 56.940—56.955 mm {2.2417—2.2423 in} 0.25 {0.010} undersize: 56.690—56.705 mm {2.2318—2.2324 in} 0.50 {0.020} undersize: 56.440—56.455 mm {2.2220—2.2226 in} 0.75 {0.030} undersize: 56.190—56.205 mm {2.2122—2.2128 in}
Crank pin wear limit	0.05 mm {0.0020 in}
Crank pin out-of-round	0.03 mm {0.0012 in}
Standard main journal clearance	No.1, 2, 4, 5: 0.027—0.045 mm {0.0010—0.0017 in} No.3: 0.044—0.062 mm {0.0017—0.0024 in}
Maximum main journal clearance	0.08 mm {0.003 in}

TECHNICAL DATA [WL-C, WE-C]

Item	Specification
Main bearing thickness	Standard: 2.006—2.021 mm {0.0789—0.0794 in} 0.25 {0.010} undersize: 2.124—2.134 mm {0.0836—0.0838 in} 0.50 {0.020} undersize: 2.249—2.259 mm {0.0885—0.0888 in} 0.75 {0.030} undersize: 2.374—2.384 mm {0.0934—0.0937 in}
Standard crankshaft end play	0.040—0.282 mm {0.0016—0.0111 in}
Maximum crankshaft end play	0.3 mm {0.01 in}
Thrust bearing thickness	Standard: 2.455—2.505 mm {0.0967—0.986 in} 0.35 {0.010} oversize: 2.630—2.680 mm {0.1036—0.1055 in}
Connecting rod bending	0.075 mm {0.0030 in} max./50 mm {2.0 in}
Connecting rod distortion	0.18 mm {0.0070 in} max./50 mm {1.968 in}
Connecting rod center-to-center distance [WL-C]	162.96—163.04 mm {5.983—5.986 in}
Connecting rod center-to-center distance [WE-C]	157.96—158.04 mm {5.983—5.986 in}
Standard connecting rod oil clearance	0.025—0.052 mm {0.0009—0.0020 in}
Maximum connecting rod oil clearance	0.08 mm {0.003 in}
Connecting rod bearing thickness	Standard: 1.507—1.516 mm {0.0592—0.0595 in} 0.25 {0.010} undersize: 1.624—1.634 mm {0.0638—0.0642 in} 0.50 {0.020} undersize: 1.749—1.759 mm {0.0687—0.0691 in} 0.75 {0.030} undersize: 1.874—1.884 mm {0.0737—0.0740 in}
Standard connecting rod side clearance	0.110—0.262 mm {0.0043—0.0103 in}
Maximum connecting rod side clearance	0.35 mm {0.014 in}
Balance shaft Standard end play	0.04—0.16 mm {0.002—0.006 in}
Standard diameter	Front: 41.945—41.960 mm {1.6514—1.6519 in} Center: 39.945—39.960 mm {1.5727—1.5732 in} Rear: 37.975—37.990 mm {1.4951—1.4956 in}
Standard clearance	Front, rear: 0.050—0.115 mm {0.0020—0.0045 in} Center: 0.080—0.145 mm {0.0032—0.0057 in}
Cylinder head bolt length	Bolt head mark W Standard length: 101.2—101.8 mm {3.985—4.007 in} Maximum length: 102.5 mm {4.035 in} Bolt head mark N Standard length: 113.2—113.8 mm {4.457—4.480 in} Maximum length: 114.5 mm {4.508 in} Bolt head mark I Standard length: 149.0—150.0 mm {5.866—5.905 in} Maximum length: 150.5 mm {5.925 in}
Main bearing cap bolt length	Standard length: 84.7—85.3 mm {3.34—3.35 in} Maximum length: 86.0 mm {3.39 in}
Connecting rod cap bolt length	Standard length: 55.45—56.05 mm {2.19—2.20 in} Maximum length: 56.75 mm {2.23 in}
Valve clearance [Engine cold]	IN: 0.10—0.16 mm {0.0040—0.0062 in} EX: 0.17—0.23 mm {0.0067—0.0090 in}
Valve clearance [Engine cold]	IN: 0.10—0.16 mm {0.0040—0.0062 in} EX: 0.17—0.23 mm {0.0067—0.0090 in}
Standard oil pump tip clearance	0.10—0.19 mm {0.0040—0.0074 in}
Maximum oil pump tip clearance	0.20 mm {0.008 in}
Standard oil pump side clearance	0.04—0.09 mm {0.0016—0.0035 in}
Maximum oil pump side clearance	0.15 mm {0.0059 in}
Standard plunger spring length	43.8 mm {1.72 in}
Front oil seal press-in amount	0.0—0.40 mm {0.0—0.015 in}
Fuel injection pump oil seal press-in amount	0.0—0.40 mm {0.0—0.015 in}
Camshaft oil seal press-in amount	0.5—1.0 mm {0.020—0.039 in}

01

SERVICE TOOLS [WL-3]

01-60A SERVICE TOOLS [WL-3]

ENGINE [WL-3] 01-60A-1

01

ENGINE [WL-3]


1: Mazda SST number

2: Global SST number



















Example

1:49 UN30 3050
2:303-050




Engine lifting
brackets



DCF01600000W01

<p>1:49 0107 680A 2:-</p> <p>Engine stand</p> 	<p>1:49 L010 1A0 2:-</p> <p>Engine hanger set</p> 	<p>1:49 0636 100B 2:-</p> <p>Valve spring lifter arm</p> 
<p>1:49 B012 0A2 2:-</p> <p>Pivot</p> 	<p>1:49 S120 170 2:-</p> <p>Valve seal remover</p> 	<p>1:49 B012 015 2:-</p> <p>Installer (Part of 49 B012 0A3)</p> 
<p>1:49 S010 001 2:-</p> <p>Oil seal installer</p> 	<p>1:49 E011 1A0 2:-</p> <p>Ring gear brake set</p> 	<p>1:49 S120 215B 2:-</p> <p>Pulley puller</p> 
<p>1:49 S011 103 2:-</p> <p>Oil seal installer</p> 	<p>1:49 S010 301 2:-</p> <p>Oil seal installer</p> 	<p>1:49 F027 009 2:-</p> <p>Oil seal installer</p> 
<p>1:49 G011 001 2:-</p> <p>Piston pin replacer</p> 	<p>1:49 L012 001 2:-</p> <p>Installer (Part of 49 L012 0A0B)</p> 	<p>1:49 L012 002A 2:-</p> <p>Body (Part of 49 L012 0A0B)</p> 
<p>1:49 L012 005 2:-</p> <p>Spacer (Part of 49 L012 0A0B)</p> 	<p>1:49 L012 003A 2:-</p> <p>Installer (Part of 49 L012 0A0B)</p> 	<p>1:49 L012 004A 2:-</p> <p>Nut (Part of 49 L012 0A0B)</p> 

SERVICE TOOLS [WL-3]

<p>1:49 UN30 3050 2:303-050</p> <p>Engine lifting brackets</p> 	<p>1:49 L017 5A0 2:-</p> <p>Support hanger</p> 	<p>1:49 9140 074 2:-</p> <p>Cam lift measuring device</p> 
--	---	---

SERVICE TOOLS [WL-C, WE-C]

01-60B SERVICE TOOLS [WL-C, WE-C]

ENGINE SERVICE TOOLS

[WL-C, WE-C] 01-60B-1

01

ENGINE SERVICE TOOLS [WL-C, WE-C]

DCF01600000W02


1: Mazda SST number
















2: Global SST number

Example

1:49 UN30 3050
2:303-050

Engine lifting
brackets



<p>1:49 0107 680A 2:-</p> <p>Engine stand</p> 	<p>1:49 L010 1A0 2:-</p> <p>Engine stand hanger set</p> 	<p>1:49 0636 100B 2:-</p> <p>Valve spring lifter arm</p> 
<p>1:49 B012 0A2 2:-</p> <p>Pivot</p> 	<p>1:49 S120 170 2:-</p> <p>Valve seal remover</p> 	<p>1:49 F027 009 2:-</p> <p>Oil seal installdr</p> 
<p>1:49 S010 001 2:-</p> <p>Oil seal installer</p> 	<p>1:49 E011 1A0 2:-</p> <p>Ring gear brake set</p> 	<p>1:49 S120 215B 2:-</p> <p>Pulley puller</p> 
<p>1:49 S011 103 2:-</p> <p>Oil seal installer</p> 	<p>1:49 S010 301 2:-</p> <p>Oil seal installer</p> 	<p>1:49 UN30 3050 2:-</p> <p>Engine lifting brackets</p> 
<p>1:49 G011 001 2:-</p> <p>Piston pin replacer</p> 	<p>1:49 B012 015 2:-</p> <p>Valve guide remover and installer</p> 	<p>1:49 L017 5A0 2:-</p> <p>Support hanger</p> 

SERVICE TOOLS [WL-C, WE-C]

1:49 B012 016

2:—

Valve seal
installer

